


User manual

Central controller with touch display

Air Center Control

ACC MT







Tal	ala af a	contents		11.8	Deleting a group	22
Idi	Jie oi c	ontents		11.9	Changing group names	22
1	Genera	al safety instructions 4		11.10	Changing the name of a unit	
		<u> </u>		11.11	Closing the group editor	22
2	Data p	rotection notices for the operator4	12	Floor p	lans/Floor plan editor	22
3	Produc	ct Description4		12.1	Overview Floor plan view	23
_	D	lium the conjunctions C		12.2	Floor plan editor	
4	Regard	ling these instructions		12.3	Overview Floor plan editor	
5	Comm	issioning6		12.4	Overview of units and groups	
	5.1	Configuration wizard 6		12.5	Upload new floor plan	
^	1141-1			12.6	Adding new floor plan	
6	initiais	setup procedure6		12.7	Assigning units to a floor plan	
7	Contro	ıls7		12.8	Selecting the floor plan	
	7.1	Dashboard 7		12.9 12.10	Deleting a unit from a floor plan	
	7.2	Header			Deleting all units from the floor plan	
	7.3	Initial Menu9		12.11 12.12	Changing the floor plan name	
	7.4	Footer			Changing the name of a unit	
	7.5	Log user in and out			Closing the Floor plan editor	
8	Onerat	ting units10		12.14	closing the Floor plan editor	21
0	8.1	Overview Operate units	13	Schedu	ıles	27
	8.2	Display variants		13.1	Overview Schedules	27
	8.2.1	Tile view		13.2	Creating a time program	28
	8.2.2	List view		13.3	Selecting a schedule	
	8.2.3	Floor Plan view		13.4	Deleting a schedule	
	8.3	Units illustration		13.5	Create time period	
	8.4	Selecting and deselecting units for editing		13.6	Deleting one or several periods from a schedule .	
	8.4.1	Select an individual unit		13.7	Deleting all periods from a schedule	
	8.4.2	Selecting several units		13.8	Copying a period to different days	
	8.4.3	Select one or several groups		13.9	Select and deselect periods to be edited	
	8.4.4	Deselecting units or groups			Selecting one or several periods	
					Selecting all periods	
9	Setting	gs sidebar			Deselecting periods	
	9.1	Settings14			Settings sidebar	
	9.1.1	Overview sidebar Settings14			1 Overview of sidebar settings, time periods	
	9.1.2	Displaying/hiding the sidebar			2 Displaying/hiding the sidebar	
	9.1.3	Operation – switching the units on and off			3 Setting the start and end time for a period	
	9.1.4	Set operating mode			4 Setting the operating mode (time periods)	
	9.1.5	Adjusting the set temperature			5 Adjusting the set temperature (time periods)	
	9.1.6	Set fan speed			6 Setting the fan speed (time periods) Assigning units	
	9.2	Settings ERV			1 Overview Assign units	
	9.2.1	Set operating mode			2 Overview of units and groups	
	9.2.2	Set fan speed			3 Selecting a schedule	
	9.3	Exiting the settings sidebar Settings			4 Assigning units to a schedule	
10	Lock M	lanager			5 Deleting a unit from a time program	
	10.1	Settings of selected units			6 Delete all units from the schedule	
	10.2	Closing the Lock manager			7 Changing the name of a unit	
4 4	C				8 Closing Assigning units	
11	-	editor			Activating time programs	
	11.1	Overview Group editor			Calling up the Calendar page	
	11.2	Overview of units and groups			Exiting the Schedules	
	11.3	Create group				
	11.4	Assigning units to a group	14		ar	
	11.5	Selecting group		14.1	Overview Calendar	
	11.6 11.7	Deleting a unit from a group		14.2	Displaying/hiding the sidebar	35
	/					



	14.3	Select or deselect schedules	35
	14.3.1	Selecting one or several schedules	35
	14.3.2	Deselecting schedules	35
	14.4	Displaying more than 4 schedules	35
	14.5	Calling up the Schedules page	36
	14.6	Changing the calendar view	36
	14.7	Select a day or a period	36
	14.8	Defining periods for time programs	36
	14.9	Ending the Calendar	36
15	Energy	management	36
	15.1	Output limitation	37
	15.1.1	Overview Output limitation	38
		Displaying/hiding the sidebar	
		Selecting port	
		Selecting and deselecting refrigerant systems	
		Setting an output restriction	
		Exiting the Output limitation	
		Energy meter editor	
		Overview, energy meter editor	
		Create an energy meter	
		Setting the energy meter	
		Assign the energy meter units	
		Replacing/removing the energy meters	
		Close the Energy meter manager	
	15.3	Energy meter monitor	
	15.3.1	Overview, energy meter monitor	
	15.4	Tenant management	
	15.4.1	Overview, tenant management	44
	15.5	Energy distribution	44
		Switch the energy distribution on / off	
	15.6	Energy report	45
	15.6.1	Energy report	46
16	Diagno	sis	47
	16.1	Fault and event history	
	16.2	System structure	
		Overview of system structure	
		Selecting port	
		Selecting refrigerant system	
		Scan VRF system (System scan)	
		Deleting unit	
		Add unit	
		Exiting the System structure	
	16.3	System monitor	
	16.3.1	Overview of system monitor	
		Selecting port	
		Selecting refrigerant system	
		Selecting display	
		Overview of measurements and parameters	
		Exiting the System monitor	
	16.4	Digital input	
17	System	configuration	
	17.1	Floor plan editor	
	17.2	Group editor	
		Set up system	

18	Contro	ller settings53
	18.1	User management54
	18.1.1	User roles
	18.1.2	Add user
	18.1.3	Deleting users55
	18.1.4	Changing user data55
	18.1.5	Closing user management
	18.2	Network settings
	18.3	Screen settings
	18.3.1	Adjusting the brightness of the display
		Setting the switch-off time of the display 57
	18.4	Language, date and time57
	18.4.1	Language 57
		Time zone, date and time57
	18.5	E-mail manager57
	18.5.1	Configuring the Outgoing server settings 57
	18.5.2	Configuring the E-mail notifications
	18.6	Device and updates
	18.6.1	Resetting all settings
		Restarting59
		Backing up and restoring settings 59
		Software update from USB stick 59
19	Help	60
20	Trouble	eshooting60
	20.1	Warnings and Errors60
	20.2	Energy Distribution
21	Enviror	nmental protection and disposal62



1 General safety instructions

⚠ Intended use

► Only use the product to control Air Flux/MDCI VRF and/or CL5000L/ Mair conditioning systems (VRF = Variable Refrigerant Flow).

All other use is considered unsuitable. Any damage resulting from unsuitable operations is excluded from liability.

⚠ Notices for the target group

These operating instructions are intended for this operation manual of the Air Flux/MDCI VRF and/or CL5000L/M air conditioning system.

All instructions must be observed. Failure to comply with instructions may result in material damage and personal injury, including danger to life.

- ► Read and retain the operation manuals of all system components (outdoor unit, indoor unit, ERV ventilation units, control units, etc.) prior to operation.
- ▶ Observe the safety instructions and warnings.

▲ Safety instructions for care and cleaning

The projected capacitive touchscreen (PCT) contains a layer of tempered glass. This could be damaged if the touchscreen is used incorrectly.

- ▶ Only operate the touchscreen with a finger or a capacitive stylus.
- Protect against sharp edges and scratching.
- ► To clean, wipe with a soft cloth.
- ▶ Do not use organic solvents, acids or alkaline solutions.
- Wipe off water or fat residue without delay.

2 Data protection notices for the operator

The operator of the ACC MT central controller (or user role administrator and expert acting on behalf of the operator) is responsible for safeguarding user data.

From the operator's standpoint, data protection comprises the following:

- Not using usernames for the user accounts that are related to the individual person.
- Use strong passwords for the user accounts that are not easy to
 guess.
- If requested to do so by the user, the operator is under obligation to delete the corresponding user account and therefore all user data.
- Name indoor units, floor plans, schedules and calendar settings in such a way that it is difficult for outsiders to identify persons or families based on these names.

3 Product Description

The Air Flux product series is an air-conditioning system solution for commercial buildings, e.g. offices, hotels or apartment complexes.

The variable refrigerant flow central controller with ACC MT (Air Center Control) touch screen – referred to as "central controller" in this document – plays a key role in the operation of the air-conditioning system. The central controller is primarily designed to be used and operated by professional users in the area of HVAC technology who are authorised to make more in-depth system settings.

The central controller controls up to 32 outdoor and 64 indoor units (or other units of the type ERV, AF-HB or AHU-KIT) via an XYE communication cable. An optional expansion card AC-EXP controls up to 128 outdoor units and 256 indoor units (or other units of the type ERV, AF-HB or AHU-KIT) via an 4 XYE communication cable.

The central controller can be operated via 3 different user levels or user roles:

- User
- Expert
- Administrator

Users with the role of "User" can control indoor units either individually or as a group via the central controller. These users can only perform the most important settings.

Users with the role of "Expert", e. g. Facility Manager, can access functions in the central controller such as grouping of indoor units, user management, assignment of user roles and a lock manager for time programs and diagnostics.

Users with the "Administrator" user role have unrestricted rights and can manage the rights of other users.

The central controller can be connected to a commercially-available PC via a local network (LAN).

Additionally, a connection to building management systems of thirdparty providers can be established via Modbus/TCP using the additional Ethernet interface provided by the expansion card AC-EXP.

Connections, to fire-alarm call points or emergency flasher systems for example, can be established by using other interfaces. Connections to other systems, such as fire-alarm systems, can be established by using the digital inputs and outputs.

To protect against unauthorised access to the central controller from the Internet:

► Use suitable firewall (→ Figure 1, page 5).

System overview




Fig. 1 VRF system overview (schematic overview; the system configuration shown is only an example, not all options are shown; the actual wiring/piping is not shown in this figure)

- 1) AC-EXP (available as an accessory).
- Adaptor AC-CM for connection of outdoor units of the type MDCI, and direct connection of selected Climate 5000L and Climate 5000M indoor units (some functions of these systems are restricted).
- Auto addressing is the default setting in the outdoor units.

 However, this only leads to a successful system scan if only one refrigerant system with address "0" is connected.

If more than one refrigerant system is connected to an XYE cable, the addressing must be carried out manually in combination with unique IDU addresses.





On one XYE, either systems using an AC-CM (MDCI, CL5000L/M), or AF5300 / AF6300, or AF4300 / AF5301 can be connected. If more than one of such combinations exist, additional XYE ports via AC-EXP are required.

4 Regarding these instructions

Further applicable documents

Docu	Document			
IM/O	IM/OM of connected system devices			
AC EX	XP (expansion card for ACC MT)			
IM AC	IM ACC MT			
IM AC	IM AC-CM (converter for outdoor units of the type MDCI)			
AD A	AD AC-PS (power supply ACC MT)			
AD	AD Installation device			
IM	IM Installation Instructions			
OM	Operation manual			
QSG	QSG Quick-Start-Guide			

Important information



The info symbol indicates important information where there is no risk to people or property.

Additional symbols

Symbol	Meaning	
>	a step in an action sequence	
\rightarrow	a reference to a related part in the document	
•	a list entry	
- a list entry (second level)		

Table 1

Abbreviations and concept application

Abbreviation/concept	Definition
ACC MT	Air Center Control with Touch Display
AF 5300/AF 5301/AF	Outdoor units
6300, etc	
AHU KIT	DX-AHU connection kit
ARC	Air Room Control (VRF wired/remote controller)
BMS	B uilding M anagement S ystem
Dashboard	Main screen on the central controller from where the user can make the most important settings.
Unit	Designation of the IDUs (indoor units) and ERV, AHU KIT and AF-HB ventilation units which are installed in the VRF system and have been detected by the central controller ACC MT. The central controller controls these units. The outdoor units are named specifically as outdoor units.
ERV	Energy Recovery Ventilation Units

Abbreviation/concept	Definition
НВ	H ydro B ox (hot water production module)
HP	Heat Pump (designation on icons representing ODUs of the type AF 5300)
HR	Heat Recovery (designation on icons representing ODUs of the type AF 6300)
IDU	Indoor Unit
IRC	Infra red controler (VRF infra-red remote control)
LAN	Local Area Network
MDCI	Compact version of a VRF system with light functional restrictions
ODU	Outdoor Unit
Port	Connection for an XYE cable. The central controller itself has an XYE port, the AC EXP expansion card offers 3 additional ports.
VRF	V ariable R efrigerant F low
WAN	Wide Area Network
XYE	Communication BUS ACC - ODU

5 Commissioning

5.1 Configuration wizard

The configuration wizard starts automatically the first time the central controller is operated after establishing the connection with the power supply.

► Follow the instructions of the configuration wizard step-by-step.

The following configurations can be made:

- · Select language, country, time zone, date and time
- · Restore saved settings
- · Perform software updates
- · Create new admin user
- · Start system scan

The first user account to be set up is a user account with administrator rights. Once the administrator account has been set up, the administrator can create new user accounts and assign user roles.



National data protection regulations must be observed when creating the user accounts (→ "Observe and comply with data protection notices for the operator" in the operating instructions).



The configuration wizard also starts once all settings have been reset. Previously saved user-specific settings can be restored during the **Select country** configuration step.

- → 18.6.1 "Resetting all settings"
- → 18.6.3 "Backing up and restoring settings"

6 Initial setup procedure

The following table shows a possible initial setup for the user with the user role Administrator. It may be advisable to take further steps, depending on the application.

I		Reference
ſ	 Perform system scan to detect all units installed in the VRF system. 	→ 16.2.4 "Scan VRF system (System scan)"
	· Create user.	→ 18.1 "User management"



	Reference
Create floor plan (if available and required).	→ 12 "Floor plans/Floor plan editor"
Create groups.	→ 11 "Group editor"
Define time programs and assign units.	→ 13 "Schedules"
Define validity of time programs created in the calendar.	→ 14 "Calendar"

7 Controls

7.1 Dashboard

After successfully logging in, the **Dashboard** page appears.



- \rightarrow 7.5 "Log user in and out"
- → 7.3 "Initial Menu" (access to further functions)

Overview Dashboard




Fig. 2 Example of display (changes are possible)

	Designation	Description/references
- ^ -	Header	Navigation element, at the top edge of the screen on every page
≡ @ 5		→ 7.2 "Header"
System status See details	System monitor	Opens the System monitor view.



	Designation	Description/references
Energy report	Energy report	Opens the Energy report view.
Squine servine 3 © 3 © 0 0 0 Newling of East	Operate units	 Edit indoor units, groups, adjust one or several units. Access tile, list and floor plan view display variants. Set functions such as Mode, Fan or Temp for selected indoor units. → 8 "Operating units" → 8.2 "Display variants" → 11 "Group editor" → 9 "Settings sidebar"
Scheduler	Schedules	 Create and edit time programs. Assign indoor units to the schedules. Set time periods and operating functions for the indoor units. → 13 "Schedules"
Settings	Controller settings	 Configure central controller. → 18.1 "User management" → 18.2 "Network settings" → 18.3 "Screen settings" → 18.4 "Language, date and time" → 18.5 "E-mail manager" → 18.6 "Device and updates"
Spatial statements	System status	 Shows all units that are switched on, and also those that are switched off, and also units that are affected by faults. Access indoor units in all display variants. → 20 "Troubleshooting" → 8 "Operating units" → 8.2 "Display variants" → 16.2 "System structure"

7.2 Header

The header is located on each side at the top edge of the screen. It makes navigation through the user interface easier.

Header overview


	Description	Description/references
	Main menu	Access functions.
		→ 7.3 "Initial Menu"
^	Dashboard	Call up the Dashboard page.
		→ 7.1 "Dashboard"
	Back	Go back to the previous page.
	Middle of the header	Shows the title of the page.
2	Logout	Log user out.



	Description	Description/references
\wedge		Call up fault and event history.Yellow symbol: pending warning.
<u> </u>		Red symbol: pending faults.
		• Symbol green checkmark: there are neither pending warnings nor faults.
		→ 16.1 "Fault and event history"
		→ 20 "Troubleshooting"
\bigcirc		
	Help	Guides to the User manual.
		→ 19 "Help"

7.3 Initial Menu

The main menu is an element of the header. Functions can be accessed via the main menu.



To call up the main menu:

► Select header > ____.

The main menu expands.

Overview Main menu

	Description	References
>		Show subfunctions.
===	Operate units	→ 8 "Operating units"
<u></u>	Schedules	→ 13 "Schedules"
	Calendar	→ 14 "Calendar"
<u></u>	Energy management	→ 15 "Energy management"
U _B	Diagnosis	→ 16 "Diagnosis"
	System configuration	→ 17 "System configuration"
(i)	Controller settings	→ 18 "Controller settings"
?	Help	→ 19 "Help"

7.4 Footer

The footer is displayed on every page at the bottom edge of the screen. The outside temperature $\clubsuit \triangle$, date, time and the user name of currently logged-in use are displayed in the footer.



7.5 Log user in and out

Logging in user

If a user is not logged in, the **Login** dialogue box appears.

To log in a user:

- ► Enter user name in the field **User name**.
- Enter password in the field Password.
- Select language via the Language dropdown list.
- Select Login.

The **Dashboard** page appears.

i

→ 7.1 "Dashboard"

Log user out

To log a user out:

► Header > A > Logoff
User is logged out. The Login dialogue box appears.



i			
→ 7	7.2 "Header"		

-or► Header > = > □□ Operate units

The **Operate units** page appears in the tile view.

i

→ 7.1 "Dashboard"

→ 7.2 "Header"


8 Operating units

All units can be operated, grouped and adjusted individually via the page **Operate units**.

To call up the page **Operate units**:

► Dashboard > ⊙ Operate units

8.1 Overview Operate units



	Description	Description/references
- ^ 6	Header	Navigation element, at the top edge of the screen on every page
≡ □ ⊃		→ 7.2 "Header"
I ♠ 29°C 20.03.2019 1:05 pm	Footer	Display of outdoor temperature, date, time and the user name of currently logged-in user
		→ 7.4 "Footer"
0	Group editor	Combining units into groups.
Group editor		→ 11 "Group editor"
Graph 《	Area Groups	Display and selection of created groups
Meeting room 1 Meeting room 2 Office to floor		Display and selection of all units
III Office 1st floor III Office 2nd floor		The Settings sidebar appears once units have been selected
		→ 8.4 "Selecting and deselecting units for editing"
Comp other		→ 9 "Settings sidebar"
	Display variants	View of Operate units page with 3 possible variants:
 FJ !!!		- Tile view
		- List view
· · · · · · · · · · · · · · · · · · ·		- Plan view
		→ 8.2 "Display variants"



	Description	Description/references
© 0001000 B CO11000 B CO11000 B 0001000 B 0001	Units view area	 Displays the units selected in the Groups area. Selection of units → 8.4 "Selecting and deselecting units for editing"
All All Running Fault Off	Dropdown list selection	Selection of units with specific attributes (e.g. switched off)
All Units	Dropdown list selection of units: • AF5300/MDCI/Split • AF6300 • AHU HP • AHU HR • ERV • AF4300/AF5301 • All Units	Selection of units → 8.4 "Selecting and deselecting units for editing"
	Select all or Select none	 Select all units. Once all units have been selected, all units can be deselected via the Select nonebutton which then appears. → 8.4 "Selecting and deselecting units for editing"

Recommendation for overview

With larger systems, the most efficient way to use the display variants is to create groups. As a recommendation, no more than 25 indoor units should be assigned to a group in order to be able to adjust them and establish an overview more quickly.



→ 11 "Group editor"

8.2 Display variants

The **Operate units** page can be displayed in 3 different views:

- 🔡 Tile view
- Same List view
- Floor plan view

The symbol for the selected view is displayed in blue.

The Group editor can be accessed via the tile and list view.

The **Floor plan editor** can be accessed via the Floor plan view.



If many indoor units are to be displayed simultaneously, there may be short delays when calling up or switching between views. The screen turns slightly darker and the message **Your request is currently being processed** appears.



The selection and setting options of the units are only described for the tile view in this documentation, but also apply for the List view and Floor plan view.



- → 11 "Group editor"
- → 12 "Floor plans/Floor plan editor"

8.2.1 Tile view

To switch from another view to the Tile view:

► Select 🔡.

The Tile view of the **Operate units** page appears. \Box is displayed in blue.

8.2.2 List view

To switch from another view to the List view:

► Select °—

The List view of the **Operate units** page appears. $\stackrel{\circ}{\circ}$ is displayed in blue.

8.2.3 Floor Plan view

To switch from another view to the Floor plan view:

► Select .

The Floor plan view on the **Operate units** page appears. : is shown in blue.



→ 12 "Floor plans/Floor plan editor"

8.3 Units illustration

On the **Operate units** page, in the units view area, the units (e.g. all units of a group) are represented that can be selected via the Groups area.



→ 8.1 "Overview Operate units"



Units illustration overview



De	escription	Description/references
Sy	/mbol unit	Unit type in the colour of the operating mode currently selected
00		→ "Overview of symbols for unit types"
		→ 9.1.4 "Set operating mode"
Meeting room 2	ame of the unit	→ 11.10 "Changing the name of a unit"
Op	perating mode and setpoint temperature	→ 9.1.4 "Set operating mode"
※ 22.0		→ 9.1.5 "Adjusting the set temperature"
Room 20°C	oom temperature	Display of current room temperature
		Display in the lower area of the tile that certain settings are blocked.
		→ 10 "Lock Manager"
<u>©</u>		• Display in the lower part of the tile that the time program to which the unit is assigned to is active.
		→ 13 "Schedules"
Off	splay Off (or other states)	 The following states can be displayed in the lower area of the tile: Unit is switched off. Unit can be reached, but has a fault. Unit cannot be reached. The operating mode selected is currently not available. → 16.2 "System structure" → 20 "Troubleshooting"

Overview of symbols for unit types

Symbol	Name of unit type
	4-way, 2-way or 1-way cassette
n	ARC group with n units (only IDUs) Several indoor units can be connected to one room controller. A so-called ARC group is thus being installed. The number of grouped units appears in the symbol for the ARC group. Settings made at the ARC or the central controller are applied to all indoor units in this group.

Symbol	Name of unit type
	Ceiling and floor unit
	Built-in ducted indoor unit
	Floor standing unit
	Wall mounted unit
5	ERV ventilation unit



Symbol	Name of unit type
	DX-AHU connection kit AHU KIT
HP	Outdoor units (ODUs) of the type AF 5300 and similar without heat recovery
HR	Outdoor unit (ODU) of the type AF 6300
<u></u>	Hot water production module AF-HB



The unit types are displayed in the colour of the assigned operating mode.

ARC groups behave like a virtual indoor unit: the same settings are displayed for all indoor units in this group. If a fault develops in one of the indoor units, the ARC group indicates a general fault display. The fault description for the individual indoor units of the ARC group can be called up from the **Fault and event history** page.



→ 16.1 "Fault and event history"

8.4 Selecting and deselecting units for editing

The units can be operated with all 3 display variants via the **Operate units** page.

To operate units individually (e.g. Set temperature, Mode, ...), units must be selected beforehand. The units are selected in the Units view area or in the Floor plans with units area.

The unit type (indoor unit, ERV, AHU KIT) can initially be selected:

Select dropdown list unit selection.

The following options can be selected:

- AF5300/MDCI/Split
- AF6300
- AHU HP
- AHU HR
- ERV
- AF4300/AF5301



- → 8.1 "Overview Operate units"
- → 12.1 "Overview Floor plan view"
- → 8.2 "Display variants"
- → 9 "Settings sidebar"

8.4.1 Select an individual unit

To select an individual unit for editing:

- Select the unit to be edited.
 - appears. Unit is selected. The Settings sidebar appears.



- → 8.3 "Units illustration"
- → 9 "Settings sidebar"

8.4.2 Selecting several units

To select several units for editing:

- ► Select the units to be edited.
 - ✓ appears. Units are selected. The Settings sidebar appears.

-or-

Select dropdown list selection.

The following options can be selected:

- **All**: all units detected by the system are displayed.
- Running: all units that are in operation are displayed.
- Fault: all units in which a fault is present are displayed.
- Off: all units that are switched off are displayed.

To select all (prefiltered) displayed units:

- Select Select all.
 - appears. Units are selected. The Settings sidebar appears.



If many indoor units are to be displayed simultaneously, there may be short delays when displaying the units. The screen turns slightly darker and the message **Your request is currently being processed** appears. To prevent this:

▶ Units can be pooled into groups on the **Group editor** page.



- → 8.1 "Overview Operate units"
- → 12.1 "Overview Floor plan view"
- → 9 "Settings sidebar"
- → 11 "Group editor"

8.4.3 Select one or several groups

Groups can be selected for editing in the Tile view and List view on the **Operate units**page.

To select a group for editing:

- ► Make sure that all units have been deselected.
- ► Select the group to be edited in the area **Groups**.
 - appears. Units belonging to the group appear in the area View of units where they can be selected.



- → 11 "Group editor"
- → 8.4.4 "Deselecting units or groups"
- → 8.4.2 "Selecting several units"
- → 8.2 "Display variants"
- → 8.1 "Overview Operate units"

8.4.4 Deselecting units or groups

To deselect selected units or groups:

▶ Select ✓.

appears. Unit or group is deselected.

To deselect all selected units:

- ► Select Select none.
 - appears. Units are deselected.



- → 8.1 "Overview Operate units"
- → 8.3 "Units illustration"
- → 11 "Group editor"



9 Settings sidebar

9.1 Settings

On the **Operate units**page (in all 3 display variants), units can be adjusted via the **Settings** sidebar.

To call up the sidebar:

Select at least one unit to be adjusted. The **Settings** sidebar appears on the left hand edge of the screen on the **Operate units** page.



If a large number of indoor units are selected at the same time, brief delays may occur when adjusting the units. The screen darkens slightly and the message **Your request is currently being processed** appears. To prevent this:

► Arrange the units into groups on the **Group editor** page.



If units are assigned to a schedule, the settings defined for the schedule apply for the units. Settings that are made for the units via the page **Operate units** are no longer valid. If a schedule is active, the settings can be changed via the central controller, ARC or IRC. These settings remain active until the next time the schedule is changed. If a period ends, the units are switched off. If a period starts, the settings defined there are applied.



- → 8.4 "Selecting and deselecting units for editing"
- → 8 "Operating units"
- → 13 "Schedules"
- → "Locking the wired remote control"
- → "Locking the infra-red remote control"
- → 8.2 "Display variants"
- → 11 "Group editor"


9.1.1 Overview sidebar Settings




In case of the AHU Kit type, only the 3 speeds can be selected. If it is CL5000L/M type, 7 fan speeds are displayed, however, only 3 fan speeds can be selected. For example, when selecting 6, it will jump after a few seconds to 7 (as it is a "high" fan speed):

- ▶ 1/2 = low speed (displayed as "1")
- ► 3/4 = mid speed (displayed as "3")
- ► 5/6/7 = high speed (displayed as "7")

View for systems with HP outdoor unit



View for systems with HR outdoor unit






Changing the view after selecting the Cooling or Heating set temperature in systems with outdoor unit AF 6300



→ 9.1.5 "Adjusting the set temperature"

View following selection of an ERV ventilation unit





Making settings → 9.2 "Settings ERV"



If several units with different setting options are selected, only the common control elements (e. g. ON/OFF) are displayed.

Description	Description/reference
Mode	Switch selected units on and off. → 9.1.3 "Operation – switching the units
	on and off"
Operating mode	• Set operating mode for selected units.
	→ 9.1.4 "Set operating mode"
Set temperature	 Adjust set temperature for selected units via rotary control (cannot be adjusted in Fan Mode). With the Auto Mode operating mode, Cooling and Heating can be adjusted for the selected units. The corresponding rotary control appears following selection.
	→ 9.1.5 "Adjusting the set temperature"
Fan speed	Set fan speed for selected units.
	→ 9.1.6 "Set fan speed"
• • •	Call up Lock manager (e.g. Lock manager).
	→ 10 "Lock Manager"
11	Hide sidebar.
$\langle \langle$	→ 9.1.2 "Displaying/hiding the sidebar"

9.1.2 Displaying/hiding the sidebar

To hide the sidebar:

► Select <<... Sidebar is hidden.

To display the sidebar:

Select >>.Sidebar is displayed.

9.1.3 Operation - switching the units on and off

Pre-selected units can be switched on and off via the \boldsymbol{Mode} area in the sidebar.

To switch off selected units that have been switched on:

► Select .

appears. The display in the sidebar changes from **Mode** ON to OFF. The selected units are displayed greyed out and **Off** is displayed in the View of units area on the **Operate units** page. Units are not in operation.



Settings can also be made for units that are not switched on, which then take effect once the units have been switched back on.

To switch on selected units that have been switched off:

► Soloct

appears. The display in the sidebar changes from **Mode** OFF to ON. The selected units are displayed in the View of units area on the **Operate units** page. The units are in operation.





- → 8 "Operating units"
- → 8.4 "Selecting and deselecting units for editing"

9.1.4 Set operating mode

The operating mode for the previously selected units can be set via the **Operating mode** area in the sidebar.

The following operating modes are available:

Symbol	Operation Mode
A	Auto Mode (only in systems with outdoor unit AF 6300)
***	Cooling mode
	Dehumidification mode
-\\	Heat mode
	Fan (Only) Mode

To set the operating mode for selected units:

Select symbol of the required operating mode (greyed out). The operating mode appears in colour and is displayed with the selected units in the Units view area on the **Operate units** page.



- → 8 "Operating units"
- → 8.4 "Selecting and deselecting units for editing"
- → 8.3 "Units illustration"

9.1.5 Adjusting the set temperature

The setting temperature for pre-selected units can be set via the Set temperature area in the sidebar.

The Set temperature area appears if one of the following operating modes is set:

- Auto Mode (only for systems with AF 6300)
- Cooling mode
- · Dehumidification mode
- Heating mode

Special feature with Auto Mode operating mode: Setting temperature can be adjusted Cooling and Heating separately. The corresponding rotary control appears after a button is selected. This means that a temperature band can be set. Cooling takes place above the upper set value (for cooling), heating takes place below the lower set value (for heating).



It is not possible to set a higher set value for Heating than for Cooling. An identical set value also cannot be set as a difference of 1 $^\circ\!C$ between the set values is always set automatically.

To adjust the set temperature for selected units:

Drag the rotary control in the

 direction or tap the semicircle
 directly at any point until the required set temperature (value in the
 centre) is displayed.

-or-

 Drag the rotary control in the — direction or tap the semicircle directly at any point until the required set temperature (value in the centre) is displayed.

The new set temperature is displayed for the selected units in the Units view area on the page **Operate units**.

Alternatively, the set temperature can also be adjusted as follows:

To return to the Cooling and Heating selection in the **Auto Mode** operating mode:

► Select X.
Rotary control is closed. The Cooling and Heating selection appears.



- → 9.1.4 "Set operating mode"
- → 8 "Operating units"
- → 8.4 "Selecting and deselecting units for editing"

9.1.6 Set fan speed

The fan speed for the previously selected units can be set via the **Fan speed** area in the sidebar.

There are 7 fan speeds: 1 has the lowest fan output rate, 7 has the highest. There are 3 fan speeds in units of the type ERV and AHU KIT. The fan speed **Auto** is also available. The fan speed is automatically adjusted in **Auto** Mode as soon as there is a difference between the set temperature and room temperature.

To set the fan speed for selected units:

Select bars of the required fan speed.
 All bars up to the selected fan speed are displayed in green.

-or-

► Select Auto.

The fan speed of the selected units is displayed in the Units view area on the **Operate units** page as a number or as **Auto**.




- → 9.1.4 "Set operating mode"
- → 8 "Operating units"
- → 8.4 "Selecting and deselecting units for editing"
- → 9.2 "Settings ERV"

9.2 Settings ERV

The sidebar for setting selected units of the type ERV can be called up via the menu item **Settings ERV**.





Description	Description/reference
Mode	Switch selected units on and off.
	→ "Operation – switching units off and on"
Operating mode	Set operating mode for selected units.
	→ 9.2.1 "Set operating mode"
Fan speed	Set fan speed for selected units.
	→ 9.2.2 "Set fan speed"

9.2.1 Set operating mode

The operating mode for the previously selected units can be set via the **Operating mode** area in the sidebar.

The following operating modes are available:

The following operating modes are available.		
Symbol	Operating mode	
	By-pass	
\rightleftharpoons	Supply and extract air mode without energy recovery. This is used for small temperature differences between the outside and inside.	
	Energy recovery	
50	To increase energy efficiency, the energy in the exhaust air is recovered by using it to heat/cool the supply air. This is used for large temperature differences between the outside and inside.	
	Auto Mode	
<u></u> ← A→	Depending on the temperature difference between the outside and inside, the ERV ventilation unit automatically switches between Bypass operating mode and Energy recovery operating mode ¹⁾ The fan speed is controlled automatically based on the CO ₂ value measured in the extract air.	
	Free cooling	
~ *	The fan speeds 1-3 (not Auto) can be set. Depending on the temperature difference between the outside and inside, the ERV ventilation unit automatically switches between Bypass operating mode and Energy recovery operating mode ²).	

- Difference inside and outside temperature ≥ 5 °C = Energy recovery operating mode; Difference indoor and outdoor temperature < 5 °C = Bypass operating mode
- 2) Room temperature < outside temperature = Energy recovery operating mode; room temperature ≥ outside temperature = Bypass operating mode

To set the operating mode for selected units:

Select symbol of the required operating mode (greyed out). The operating mode appears in colour and is displayed with the selected units in the Units view area on the **Operate units** page.



- → 8 "Operating units"
- → 8.4 "Selecting and deselecting units for editing"
- → 8.3 "Units illustration"

Operation - switching units off and on

Previously selected ERV units can be switched off and on via the **Mode** area in the sidebar.

To switch off selected units that are switched on:

► Select ______.

appears. The display in the sidebar changes from **Mode** ON to OFF. The selected units are greyed out and displayed as **Off** in the Units view area on the **Operate units** page. Units are not in operation.



Settings can also be made for units that are switched off and are applied when the units are switched back on.

To switch on selected ERV units that are switched off:

► Select

appears. The display in the sidebar changes from **Mode** OFF to ON. The selected units appear in the Units view area on the **Operate units** page. The units are in operation.



- → 8 "Operating units"
- → 8.4 "Selecting and deselecting units for editing"

9.2.2 Set fan speed

The fan speed for the previously selected units can be set via the **Fan speed** area in the sidebar.

The fan speed can only be selected and adjusted if one of the following operating modes is set:

- · Bypass operating mode
- Energy recovery operating mode
- · Free cooling operating mode

There are 3 fan speeds: 1 has the lowest fan output rate, 3 has the highest. The fan speed **Auto** is also available. The fan speed is automatically adjusted in **Auto** Mode as soon as there is a difference between the set temperature and room temperature.

To set the fan speed for selected units:

Select bars of the required fan speed.
 All bars up to the selected fan speed are displayed in green.

-or-

Select Auto.

The fan speed of the selected units is displayed in the Units view area on the **Operate units** page as a number or as **Auto**.





- → 9.2.1 "Set operating mode"
- → 8 "Operating units"
- → 8.4 "Selecting and deselecting units for editing"

9.3 Exiting the settings sidebar Settings

To return to the **Groups** area (after editing the units):

► Deselect all units.
The **Groups** area (groups/floor plans) appears.



- → 8 "Operating units"
- → 12 "Floor plans/Floor plan editor"
- → 8.4 "Selecting and deselecting units for editing"

10.1 Settings of selected units

Settings of selected units can be locked for changes via menu item Lock manager.

g .	
Range	Description/references
Min. cool. temp	 Set the lower temperature limit for operating mode cooling mode; only these or higher temperatures can be set with this. "Setting cooling limit"
Max. heat. temp	Set the upper temperature limit for operating mode heating mode; only these or low temperatures can be set with this.
	→ "Setting heating limit"
Lock operating mode	 Lock heating mode only and cooling mode only operation mode for setting changes, or off mode to cancel this lock. "Disabling operating mode"
	Example: if the operating mode is locked in "heating mode only" operating mode, all other operating modes cannot be set.
Lock IRC	Lock the VRF infra-red remote control ARC C IR. Changes to the settings are no longer possible via VRF infra-red remote control.
	→ "Locking the infra-red remote control"
Lock ARC	Lock the VRF cable remote control ARC. Changes to the settings are no longer possible via VRF cable remote control ARC.
	→ "Locking the wired remote control"
Lock fan settings	 Lock set fan speed for setting changes. → "Locking the fan settings"

Setting cooling limit

A temperature limit can be set for pre-selected units in the **Min. cool. temp** area of the Lock Manager.

The specified lower temperature limit cannot be undercut when modifying the settings for the units.

To set the lower temperature limit in Cooling mode for selected units:

- Select temperature value in the area Min. cool. temp.
 Control dial appears.
- ► Drag the control dial in the
 direction, or touch the semicircle directly at any given point, until the required lower temperature limit (temperature value displayed in the centre) is reached.

-or-

10 Lock Manager

Lock manager can be made for selected units via the **Settings** sidebar.

To call up the Lock manager:

► Select • • • .



→ 8.4 "Selecting and deselecting units for editing"

 Drag the control dial in the — direction, or touch the semicircle directly at any given point, until the required lower temperature limit (temperature value displayed in the centre) is reached.

Alternatively, the lower temperature limit can also be adjusted as follows:

 Select + or — until the required lower temperature limit is reached.

To apply the new temperature value:

► Select X.

Control dial closes. The lower temperature limit is set. appears in the area View of units on the **Operate units** page next to the selected units.



→ 8.4 "Selecting and deselecting units for editing"

Setting heating limit

An upper temperature limit can be set for pre-selected units in the **Max. heat. temp** area of the Lock Manager.

The specified upper temperature limit cannot be exceeded when modifying the settings for the units.

To set the upper temperature limit for selected units in Heating mode:

- ► Select temperature value in the area **Max. heat. temp**. Control dial appears.

-or-

 Drag the control dial in the — direction, or touch the semicircle directly at any given point until the required set upper temperature limit (temperature value displayed in the centre) is reached.

Alternatively, the upper temperature limit can also be adjusted as follows:

 Select + or — until the desired upper temperature limit is reached.

To apply the new temperature value:

► Select X.

Control dial closes. The upper temperature limit is set. appears in the area View of units on the **Operate units** page next to the selected units.



→ 8.4 "Selecting and deselecting units for editing"



Disabling operating mode

The following operating modes can be disabled for pre-selected units in the **Lock operating mode** area of the Lock manager:

- Heating mode only: the unit is blocked in Heating mode. Another operating mode cannot be set.
- Cooling mode only: the unit is blocked in Cooling mode only.
 Another operating mode cannot be set.

To lock one of the operating modes for selected units:

► Select ✓.

Dropdown list is expanded.

► Select operating mode to lock to.

The selected operating mode is highlighted in blue and applied.

appears in the area View of units on the **Operate units** page next to the selected units.

To unlock an operating mode:

► Select ✓.

Dropdown list is expanded.

► Select Off.

The locked operating mode is unlocked. \bigcirc disappears in the area View of units on the **Operate units**page next to the selected units.



→ 8.4 "Selecting and deselecting units for editing"

Locking the infra-red remote control

The infra-red remote control ARC C IR can be used to adjust units independently of the central controller.

The infra-red remote control can be disabled for pre-selected units in the **Lock IRC** area of the Lock Manager.

To disable use of the infra-red remote control for selected units:

► Select

appears. Infra-red remote control is locked.

appears in the area View of units on the **Operate units** page next to the selected units.

To cancel the remote control interlock:

► Select _____.

appears. Settings can be made via the infra-red remote control.



- → 8.4 "Selecting and deselecting units for editing"
- → 8.3 "Units illustration"

Locking the wired remote control

The wired remote control ARC can be used to adjust units independently of the central controller.

The ARC can be disabled for pre-selected units in the **Lock ARC** area of the Lock Manager.

To disable the ARC for selected units:

► Select .

appears. ARC is locked.

appears in the area View of units on the **Operate units** page next to the selected units.

To unlock the ARC:

► Select



appears. Settings can be made via the ARC.



- → 8.4 "Selecting and deselecting units for editing"
- → 8.3 "Units illustration"

Locking the fan settings

The set fan speed can be locked for pre-selected units in the **Lock fan settings** area of the Lock Manager.

To lock the fan speed for selected units:

► Select ...

appears. The fan speed set for the unit(s) has been locked.

appears in the area View of units on the **Operate units** page next to the selected units.

To cancel the interlock of the set fan speed:

► Select

appears. The fan speed can be adjusted for the selected units.



- → 8.4 "Selecting and deselecting units for editing"
- → 8.3 "Units illustration"

10.2 Closing the Lock manager

To close the Lock manager:

► Select X.

The Lock manager have been closed.

11 Group editor

Units can be arranged in groups via the **Group editor** page.

Examples:

- In an office building, all offices belong to one group. Meeting rooms are assigned to another group.
- All units on the North side or South side are assigned to the respective groups.



The **Group editor** page can only be called up via the **Operate units** page if all units have been deselected.

→ 8.4.4 "Deselecting units or groups"

To call up the page **Group editor**:

► Dashboard > ⊙ • • • • Operate units > Tile or List view on the page Operate units > Group editor


-or-



- → 7.2 "Header"
- → 8.1 "Overview Operate units"
- → 8.2 "Display variants"



11.1 Overview Group editor



Description	Description/References
Header	Navigation element, on every page at the top edge of the screen
	→ 7.2 "Header"
	→ 11.11 "Closing the group editor"
Footer	Display of outside temperature, date and time
	→ 7.4 "Footer"
Select units area	View and selection of groups and units
	Change names of units.
	→ 11.2 "Overview of units and groups"
	Create new group.
	→ 11.3 "Create group"
	Display/hide units.
	→ 11.2 "Overview of units and groups"
	Assign selected units to a group.
	→ 11.4 "Assigning units to a group"
	Change groups and unit names.
	→ 11.9 "Changing group names"
	→ 11.10 "Changing the name of a unit"
	→ 11.8 "Deleting a group"
	-ooter



	Description	Description/References
Office 1st floor Charging	Right frame	View of a selected group.
Flort I X		Assign units to a group.
		Confirm and Cancel
		→ 11.4 "Assigning units to a group"
\ /		Delete individual unit.
X		→ 11.6 "Deleting a unit from a group"
	Clear group	Delete all units of a selected group.
Clear group		→ 11.7 "Deleting all units in a group"

11.2 Overview of units and groups

The **Group editor** page in the **Select units** area contains an overview of the units, arranged into 3 categories:

- · Not grouped: all units that are not assigned to any group.
- All units: all units that have been detected by the system and created.
- If groups have been created, the units assigned to these groups are displayed under these groups.

To display units:

► Select ✓.
Units are displayed.



→ 16.2.4 "Scan VRF system (System scan)"

11.3 Create group

To create a new group:

► + Select in the **Select units** area.

The **New group** dialogue box appears.

- ► Enter group name in the **Group name** field.
- ▶ Select Confirm.

The new group appears in the View area.

To cancel the operation:

► Select Cancel.



- → 11.4 "Assigning units to a group"
- → 11.1 "Overview Group editor"

11.4 Assigning units to a group

To assign units to a group:

- ► Expand the categories **All units** and/or **Not grouped**.
- ► Select of the units to be assigned to the group.
 - appears. Units are selected.
 - \rightarrow appears.
- ► Select →.

-or-

Drag and drop individual unit into the View area.
 Units are assigned to the group and appear in the View area.

Confirm and Cancel appear.

► Select Confirm.

The group containing the assigned units is available in the system. Group appears in the **Select units** area.

To cancel the operation:

▶ Select Cancel.

To assign additional units to an existing group:

 Select the group to which the units are to be added in the Select units area.

Units can be assigned as described above.



One unit can also be assigned to several groups.



As a recommendation, no more than 25 indoor units should be assigned to a group in order to be able to adjust them and establish an overview more quickly.



- → 11.2 "Overview of units and groups"
- → 11.5 "Selecting group"

11.5 Selecting group

To select a group (e.g. in order to assign or delete units):

Select group in the **Select units** area. The group is highlighted in blue and the group and units that have already been added are displayed in the View area.

11.6 Deleting a unit from a group

To delete a unit from a group:

- ► Select group from which units are to be deleted; the units of the group are displayed in the View area.
- ► Select × to the right of the unit.
- ► Select Confirm.

The unit is deleted from the group and appears under **Not grouped** unless it is assigned to another group.

To cancel the operation:

► Select Cancel.

Individual units can also be deleted from an expanded group in the **Select units** area.



- → 11.5 "Selecting group"
- → 11.1 "Overview Group editor"

11.7 Deleting all units in a group

To delete all units in a group at the same time:

- ► Select group from which all units are to be deleted; the units of the group are displayed in the View area.
- ► Select Clear group.



► Select Confirm.

All units are deleted from the group and appear under **Not grouped** unless they are assigned to another group.

To cancel the operation:

► Select Cancel.



- → 11.5 "Selecting group"
- → 11.1 "Overview Group editor"

11.8 Deleting a group



Once a group has been deleted, users assigned to this group via the **User** management page can no longer access the units assigned to it.

To delete a group:

- ► Select to the right of the group in the **Select units** area. The warning message **Delete group** appears.
- ► Select **OK**.

Group has been deleted.

Units that were assigned to the group appear under **Not grouped** unless they have been assigned to other groups.

To cancel the operation:

► Select Cancel.



- → 11.1 "Overview Group editor"
- → 11.2 "Overview of units and groups"
- → 18.1.2 "Add user"

11.9 Changing group names

To change a group name:

- ► Select _ to the right of the group in the **Select units** area. The **Edit group name** dialogue box appears.
- ► Enter new group name in the field.
- ► Select Confirm.

Group name has changed. The group appears with the new group name in the View area.

To cancel the operation:

► Select Cancel.



- → 11.1 "Overview Group editor"
- → 11.2 "Overview of units and groups"

11.10 Changing the name of a unit

To change the name of a unit:

- Expand the category/group to which the units to be edited belong to display the units in the **Select units** area.
- ► Select _ to the right of the unit in the **Select units** area. The **Rename unit** dialogue box appears.
- Enter new name of the unit in the field.
- ► Select Confirm.

The name of the unit has changed.

To cancel the operation:

► Select Cancel.

_		_
	•	
	_	
	1	

- → 11.1 "Overview Group editor"
- → 11.2 "Overview of units and groups"

11.11 Closing the group editor

To close the page **Group editor**:

► Select header > ☐. **Dashboard** appears.



→ 7.2 "Header"

12 Floor plans/Floor plan editor

Units can be edited and adjusted individually via the **Operate units** page in the Floor plan view.

► **Dashboard** > ③ • 2 • • • Floor plans

-or-

► Header > = > □□Operate units > Display variant □

The **Operate units**page in the Floor plan view appears.

The **Floor plan editor** page can be accessed via the Floor plan view page.



- → 8 "Operating units"
- → 9 "Settings sidebar"
- → 8.2 "Display variants"
- → 7.2 "Header"



12.1 Overview Floor plan view



	Description	Description/references
	Header	Navigation element, at the top edge of the screen on every page
= ⋒ 5		→ 7.2 "Header"
_ ш э		→ 12.14 "Closing the Floor plan editor"
	Footer	Display of outdoor temperature, date and time
Il 29°C 20.03.2019 1:05 pm		→ 7.4 "Footer"
	Floor plan editor	Add floor plans.
Floor plan editor		Assign units to floor plans.
		→ 12.2 "Floor plan editor"
Floor plan view 《	Floor plan view area	Display and selection of created floor plans
Basement		The Settings sidebar appears once units have been selected.
✓ Hostel		→ 9 "Settings sidebar"
		→ 8 "Operating units"
Floor plan editor		
	Display variants	View of Operate units page with 3 possible variants:
		- Tile view
		- List view
		- Plan view
		→ 8.2 "Display variants"



Description	Description/references
Floor plans with units area	 Displays the floor plans selected in the Floor plan view area. Select units. → 8.4 "Selecting and deselecting units for editing"
Select all or Select none	 Select all units. Once all units have been selected, all units can be deselected via the Select none button which then appears. → 8.4 "Selecting and deselecting units for editing"

12.2 Floor plan editor

Floor plans can be uploaded, edited and units assigned to the floor plans on the **Floor plan editor** page.



The **Floor plan editor** page can only be called up if all units have been deselected.

ightarrow 8.4 "Selecting and deselecting units for editing"


To call up the page **Floor plan editor**:

- ► Dashboard > ③ • Floor plans > Floor plan editor or •



- → 12.1 "Overview Floor plan view"
- → 7.2 "Header"

12.3 Overview Floor plan editor



	Description	Description/References
	Header	Navigation element, on every page at the top edge of the screen
= ⋒ 5		→ 7.2 "Header"
= 回 つ		→ 12.14 "Closing the Floor plan editor"
	Footer	Display of outside temperature, date and time
♣ 24 °C 18.06.2024 01:36		→ 7.4 "Footer"



	Description	Description/References
	Select units area	View of groups and selection of units
Floor plan view		Change names of units.
Hotel		→ 12.4 "Overview of units and groups"
		→ 12.13 "Changing the name of a unit"
Floor plan editor		
		Display/hide units.
		→ 12.4 "Overview of units and groups"
	Floor plan selection dropdown list	Select floor plan.
Hotel		→ 12.8 "Selecting the floor plan"
Floor plan editor		
		Create new floor plan.
+		→ 12.5 "Upload new floor plan"
		→ 12.6 "Adding new floor plan"
_Ø		Edit floor plan and unit name.
		→ 12.11 "Changing the floor plan name"
_6		→ 12.13 "Changing the name of a unit"
_		→ 12.12 "Deleting a floor plan"
ПП		
	View area	View of a selected floor plan. Confirm and Consol.
00000 00000 00000 00000 00000 00000 0000		Confirm and Cancel 13.9 (Salesting the flee and all)
		→ 12.8 "Selecting the floor plan"
) 10 0 HD 11
	Unit on the floor plan image	→ 12.9 "Deleting a unit from a floor plan"
Room 25 °C		
25 °C		

12.4 Overview of units and groups

The **Floor plan editor** page in the **Select units** area contains an overview of the units, arranged into 2 categories:

- All units: all units that have been detected by the system and created.
- If groups have been created, the units assigned to these groups will be displayed under these groups.

To show the units in the 2 categories:

► Select ✓.
Units are displayed.



- → 16.2.4 "Scan VRF system (System scan)"
- → 11 "Group editor"

12.5 Upload new floor plan

Requirements for floor plan files:

- · Format: PNG, JPEG, JPG or GIF
- Size: no more than 25 megabytes
- Resolution: no more than 20 megapixels

To upload a new floor plan from USB:

► Select +.

The **New floor plan** dialogue box appears. The directory structure of the USB stick is displayed under **Select file**.

- ► Select floor plan.
- ► Enter name of floor plan in the **Enter name** field.
- Select Confirm.

Floor plan is displayed in the **Select file** dropdown list and can be added.

To cancel the operation:

► Select Cancel.

12.6 Adding new floor plan

To add a new floor plan that has already been uploaded to the **Floor plan** view:

▶ Select +.

The **New floor plan** dialogue box appears.

- ► Select floor plan via **Select file** dropdown list.
- ► Enter floor plan name in the field **Enter new floor plan name**.
- ► Select Confirm.

New floor plan appears in the View area.

To cancel the operation:

► Select Cancel.



For the new floor plan to be available in the system, at least one unit must be assigned to the floor plan.



- → 12.5 "Upload new floor plan"
- → 12.3 "Overview Floor plan editor"
- → 12.7 "Assigning units to a floor plan"

12.7 Assigning units to a floor plan

To assign units to a floor plan:

- ► Expand groups and/or **All units**.
- Drag-and-drop the individual unit into the floor plan in the View area. The unit is assigned to the floor plan and appears on the floor plan.
- ► Select Confirm.

The floor plan with the assigned units is available in the system. The floor plan can be selected via the Floor plan selection dropdown list on the **Floor plan editor** page.

To cancel the operation:

► Select Cancel.

To assign additional units to an existing floor plan:

 Select floor plan to which additional units are to be assigned via the Floor plan selection dropdown list.

Units can be assigned as described above.



- → 12.8 "Selecting the floor plan"
- → 12.4 "Overview of units and groups"

12.8 Selecting the floor plan

To select a floor plan:

- ► Select Floor plan selection dropdown list.
- ► Select floor plan.

Selected floor plan appears in the View area.



→ 12.3 "Overview Floor plan editor"

12.9 Deleting a unit from a floor plan

To delete a unit from a floor plan:

- Select the floor plan from which the units are to be deleted so that the floor plan and assigned units appear in the View area.
- Select the unit on the floor plan image. The unit has been deleted from the floor plan.



- → 12.8 "Selecting the floor plan"
- → 12.3 "Overview Floor plan editor"

12.10 Deleting all units from the floor plan

To delete all units from a floor plan at the same time:

- Select the floor plan containing all units you wish to delete.
- ► Select Clear floor plan.

All units have been deleted from the floor plan.



To be able to save a floor plan, at least one unit must be assigned to the floor plan.

- ► Assign at least one unit to the floor plan.
- Select Confirm.

The floor plan is displayed with the newly assigned units.

To cancel the operation:

► Select Cancel.



- → 12.8 "Selecting the floor plan"
- → 12.3 "Overview Floor plan editor"
- → 12.7 "Assigning units to a floor plan"

12.11 Changing the floor plan name

To change a floor plan name:

- ► Select the floor plan to be edited.
- ► Select Ø.

The **Edit floor plan** dialogue box appears.

- ► Enter new floor plan name in the **Enter new floor plan name** field.
- ► Select Confirm.

The floor plan name is changed and the new name appears in the Floor plan selection dropdown list.

► In the Floor plan editor, select Confirm.

The operation is complete.

To cancel the operation:

► Select Cancel.



- → 12.8 "Selecting the floor plan"
- → 12.3 "Overview Floor plan editor"

12.12 Deleting a floor plan

To delete a floor plan:

- ► Select the floor plan to be deleted.
- ► Select iii.

The warning message **Warning** appears.

► Select **Delete**.

The floor plan is deleted.

To cancel the operation:

► Select Cancel.



- → 12.8 "Selecting the floor plan"
- → 12.3 "Overview Floor plan editor"



12.13 Changing the name of a unit

To change the name of a unit:

- ► Expand the category/group to which the units to be edited belong to display the units in the **Select units** area.
- ► Select _ to the right of the unit in the **Select units** area. The **Rename unit** dialogue box appears.
- ► Enter new name of the unit in the field.
- ➤ Select **Confirm**.

 The name of the unit has changed.

To cancel the operation:

► Select Cancel.




- → 12.3 "Overview Floor plan editor"
- → 12.4 "Overview of units and groups"

12.14 Closing the Floor plan editor

To close the page Floor plan editor:

► Select header > ☐.

Dashboard appears.



13 Schedules

Time programs and corresponding time zones with defined settings (e.g. operating mode, set temperature) can be created on the **Schedules** page. Units can be assigned to these time programs.

To call up the **Schedules** page:

-or-


► Header > = > Chedules

-or-



- → 7.1 "Dashboard"
- → 7.2 "Header"
- → 14 "Calendar"

13.1 Overview Schedules



	Description	Description/references
	Header	Navigation element, at the top edge of the screen on every page
= 6 5		→ 7.2 "Header"
		→ 13.14 "Exiting the Schedules"
	Footer	Display of outdoor temperature, date and time
In 29°C 20.03.2019 1:05 pm		→ 7.4 "Footer"



	Description	Description/references
	Schedules area	Display and selection of created time schedule
Schedules + «		The Settings appears once time zones have been selected
00.00.2019-31.12.2019		→ 13.3 "Selecting a schedule"
00.00.2019-31.12.2019		→ 13.12 "Activating time programs"
05.05.2059-35.12.2059		→ 13.4 "Deleting a schedule" → 13.10 "Settings sidebar"
Exhibition 👚 🗀		7 13.10 Settings sidebal
1		Create time schedule.
十		→ 13.2 "Creating a time program"
11		Hide sidebar.
(→ 13.10.2 "Displaying/hiding the sidebar"
		Activate/deactivate time schedule.
		→ 13.12 "Activating time programs"
	View area	View and edit a selected time schedule.
		Select a period for processing.
Conto		Confirm and Cancel
To the state of th		→ 13.9 "Select and deselect periods to be edited"
_		Sidebar: delete time schedule.
		View area: deleting a time period.
		→ 13.4 "Deleting a schedule"
		→ 13.6 "Deleting one or several periods from a schedule"
Assign units	Assign units	Assign units to a time schedule.
		→ 13.11 "Assigning units"
-		Call up the Calendar page.
		→ 14.5 "Calling up the Schedules page"
	New period	Assign new period to a time schedule.
New period		→ 13.5 "Create time period"
	Copy to	Transfer period and settings to other days.
Copy to		→ 13.8 "Copying a period to different days"
	Select all or Select none	Select all periods for processing.
		Once all periods have been selected, all periods can be deselected via
		the Select none button which then appears.
		→ 13.9.2 "Selecting all periods"

13.2 Creating a time program



Personal data and settings are stored locally on the central controller and can be viewed by other users if required.

To create a time program:

- ► + Select in the Schedules area.
 The Schedules dialogue box appears.
- ▶ Enter the name of the time program in the **Schedule name** field.
- ▶ In the dropdown list, select the unit type **Select type of schedules**.
- ► Select Confirm.

The time program appears in the Schedules area.

To cancel the operation:

► Select Cancel.



→ 13.1 "Overview Schedules"

13.3 Selecting a schedule

To select a schedule (e.g. to create periods):

► Select schedule in the sidebar in the **Schedules** area.

The selected schedule is highlighted blue in the **Schedules** area. The schedule appears in the View area and can be edited.



→ 13.1 "Overview Schedules"

13.4 Deleting a schedule

To delete a schedule:

 Select to the right of the schedule in the sidebar in the area Schedules.

The **Delete selected schedule?** dialogue box appears.

Select Confirm.

The schedule is deleted.

To cancel the operation:

► Select Cancel.





→ 13.1 "Overview Schedules"

13.5 Create time period



Up to 3 time periods can be defined for each day.

To create a time period for a time program:

- ► Select the time program for which a period is to be created; the time program appears in the View area.
- ► Select New period.

Selection window **Select day(s)** appears.

- Select next to the desired day.
 - appears. Day for which the new time period applies is selected.

To close the selection window and accept the time period:

Select the selection window. Selection window is closed. Time period is created and selected. The Settings sidebar appears.



So that the new time period is available in the system, the time period must be set via the Settings sidebar.

To cancel the operation:

► Select Cancel.



- → 13.3 "Selecting a schedule"
- → 13.10 "Settings sidebar"
- → 13.1 "Overview Schedules"

13.6 Deleting one or several periods from a schedule

To delete one or several periods from a schedule:

- Select the schedule you wish to delete the period from.
- ► Select the period to be deleted in the View area.
- ► Select m in the View area.
- Select Confirm.

The period is deleted from the schedule.

To cancel the operation:

► Select Cancel.



- → 13.9 "Select and deselect periods to be edited"
- → 13.3 "Selecting a schedule"
- → 13.1 "Overview Schedules"

13.7 Deleting all periods from a schedule

To delete all periods from a schedule at the same time:

- Select the schedule from which you wish to delete all periods.
- ▶ Select Select all.

All periods of the schedule are selected.

- ▶ Select 而.
- ► Select Confirm.

All periods are deleted from the schedule.

To cancel the operation:

► Select Cancel.



- → 13.3 "Selecting a schedule"
- → 13.9 "Select and deselect periods to be edited"
- → 13.1 "Overview Schedules"

13.8 Copying a period to different days

Once a period has been set via the **Settings** sidebar, it can be copied from one day to other days.

To copy one period (or a maximum of 3 periods):

- Select the period you wish to copy.
- Select Copy to.

The **Select day(s)** list box is displayed.

Select next to the day(s) you want to copy the selection to.
 appears. The day(s) is (are) selected.

To close the list box and apply the selected days:

Select the symbol of the list box.
 The list box closes. The period is copied and appears in the View area.



- → 13.10 "Settings sidebar"
- → 13.9 "Select and deselect periods to be edited"
- → 13.1 "Overview Schedules"

13.9 Select and deselect periods to be edited

Periods can be operated in the same manner as units via the **Schedules** page.

To operate periods individually (e.g. set **Operating mode**, **Set temperature**), periods must have been selected beforehand in the View area.



- → 13.1 "Overview Schedules"
- → 13.10 "Settings sidebar"
- → 13.3 "Selecting a schedule"

13.9.1 Selecting one or several periods

To select one or several periods for editing:

Select for the periods you wish to edit.
 appears. The periods are selected. The Settings sidebar appears.



- → 13.3 "Selecting a schedule"
- → 13.10 "Settings sidebar"

13.9.2 Selecting all periods

To select all periods of a schedule you wish to edit:

► Select Select all.

✓ appears. All periods are selected. The **Settings** sidebar appears.



- → 13.3 "Selecting a schedule"
- → 13.10 "Settings sidebar"

13.9.3 Deselecting periods

To deselect selected periods:

- Select to uncheck it.
 - appears. The period is deselected.



To deselect all selected periods:

- ► Select Select none.
 - appears. Periods are deselected.




→ 13.3 "Selecting a schedule"

13.10 Settings sidebar

Time periods can be edited via the Settings sidebar.

13.10.1 Overview of sidebar settings, time periods



Auto Mode is only available in systems with outdoor unit AF 6300

To call up the sidebar:

 Select at least one time period to be edited.
 The Settings sidebar appears on the left screen margin of the Schedules page.



All settings can also be made for selected units before applying the settings with **Confirm**.



→ 13.9 "Select and deselect periods to be edited"

Description	Description/Reference
Start and End	Define start and end time for selected periods.
	→ 13.10.3 "Setting the start and end time for a period"
Operating mode	Set operating mode for selected periods.
	→ 13.10.4 "Setting the operating mode (time periods)"
Set temperature	Adjust the set temperature for selected periods via the control dial (not in Fan (Only) Mode).
	→ 13.10.5 "Adjusting the set temperature (time periods)"
Fan speed	Set fan speed for selected periods.
	→ 13.10.6 "Setting the fan speed (time periods)"
11	Hide sidebar.
((→ 13.10.2 "Displaying/hiding the sidebar"



Settings of ERV ventilation units:

→ 13.10 "Settings sidebar" → 9.2 "Settings ERV"

13.10.2 Displaying/hiding the sidebar

To hide the sidebar:

► Select <<... Sidebar is hidden.

To display the sidebar:

► Select ≫. Sidebar is displayed.

13.10.3 Setting the start and end time for a period

The start and end time can be set for selected periods via the **Settings** sidebar. The periods and corresponding settings apply for the assigned units in this time window.

To adjust the start time for a period:

- ► Make sure that only **one** period per day is selected.
- Select time under **Start**. The list boxes appear.
- Set the hours and minutes of the start time via the corresponding list box.
- ► Select Confirm.

The start time for the selected period is set.

To adjust the end time for a period:

► Make sure that only one period per day is selected.



Select time under End.

The list boxes appear.

- Set the hours and minutes of the end time via the corresponding list box.
- ► Select Confirm.

The end time for the selected period is set.

The unit is positioned accordingly in the View area on the **Schedules** page.

To cancel the time setting operation:

▶ Select Cancel.

To apply the settings:

► Select **Confirm** in the View area.

To cancel the operation:

► Select **Cancel** in the View area.



- → 13.9 "Select and deselect periods to be edited"
- → 13.1 "Overview Schedules"

13.10.4 Setting the operating mode (time periods)

The operating mode for the previously selected (multiple) time periods can be set via the **Operating mode** area in the Settings sidebar.

The following operating modes are available:

Symbol	Operation Mode
A	Auto Mode (only in systems with outdoor unit AF 6300)
***	Cooling mode
(a)	Dehumidification mode
-\\	Heat mode
	Fan (Only) Mode

To set the operating mode for selected time periods:

Select symbol of the required operating mode (greyed out). The operating mode is displayed in colour with the selected time periods in the View area on the **Schedules** page.

To apply the settings:

► Select Confirm.

To cancel the operation:

Select Cancel.



- → 13.9 "Select and deselect periods to be edited"
- → 13.1 "Overview Schedules"

13.10.5 Adjusting the set temperature (time periods)

The set temperature for previously selected time periods can be set via the **Set temperature** area in the Settings sidebar.

The **Set temperature** area can only be set for one of the following operating modes:

- Auto Mode (only for systems with AF 6300)
- · Cooling mode
- · Dehumidification mode
- · Heat mode

To adjust the set temperature for selected time periods:

- Select indicated temperature.
- The rotary control for adjusting the temperature appears.
- ► Drag the rotary control in the direction or tap the semicircle directly at any point until the required set temperature (value in the centre) is displayed.

-or-

 Drag the rotary control in the — direction or tap the semicircle directly at any point until the required set temperature (value in the centre) is displayed.

Alternatively, the set temperature can also be adjusted as follows:

▶ Select + or — until the required set temperature is obtained.

To apply the new temperature value:

► Select X.

Rotary control is closed. The new set temperature is displayed for the selected time periods in the View area on the **Schedules** page.

To apply the settings:

► Select **Confirm** in the View area.

To cancel the operation:

► Select **Cancel** in the View area.



- → 13.10.4 "Setting the operating mode (time periods)"
- → 13.9 "Select and deselect periods to be edited"
- → 13.1 "Overview Schedules"

13.10.6 Setting the fan speed (time periods)

The fan speed for the previously selected time periods can be set via the **Fan speed** area in the sidebar.

There are 7 fan speeds: 1 has the lowest fan output rate, 7 has the highest. There are 3 fan speeds in units of the type ERV and AHU KIT. The fan speed **Auto** is also available. The fan speed is automatically adjusted in **Auto** Mode as soon as there is a difference between the set temperature and room temperature.

To set the fan speed for selected time periods:

► Select bars of the required fan speed.
All bars up to the selected fan speed are displayed in green.

-or-

▶ Select Auto.

To apply the settings:

► Select **Confirm** in the View area.

To cancel the operation:

► Select **Cancel** in the View area.



- → 13.10.4 "Setting the operating mode (time periods)"
- → 13.9 "Select and deselect periods to be edited"
- → 13.1 "Overview Schedules"
- → 9.2 "Settings ERV"

13.11 Assigning units

Units can be assigned to time programs via the **Assign units** page. The settings in the time programs (e.g. operating mode at specific times) are then valid for the assigned units.





If units are assigned to a time program, the settings defined for the time program apply for the units. Settings that have been made for the unit on the **Operate units**page no longer apply. If a time program is active, the settings can be changed via the central controller, ARC or IRC. These settings remain active until the next time the time program is changed. If a time period ends, the units are switched off. If a time period begins, the settings defined there are carried out.

To call up the **Assign units** page:

► Dashboard > □ Schedules > Assign units


-or

► Header > = > Co Schedules > Assign units



- → 8 "Operating units"
- → 7.2 "Header"
- → 7.1 "Dashboard"

13.11.1 Overview Assign units



	Description	Description/References
≡ @ ⊅	Header	 Navigation element, on every page at the top edge of the screen → 7.2 "Header" → 13.11.8 "Closing Assigning units"
ia 29°C 20.03.2019 1:05 pm	Footer	• Display of outside temperature, date and time → 7.4 "Footer"
5 min turbs	Select units area	 Overview of units and groups → 13.11.2 "Overview of units and groups" → 13.11.4 "Assigning units to a schedule" → 13.11.7 "Changing the name of a unit"
Exhibition Children Summer - North Summer - South Winter	Time program selection dropdown list	• Select a schedule. → 13.11.3 "Selecting a schedule"
\		Display/hide units. → 13.11.2 "Overview of units and groups"
\rightarrow		 Assign units to a schedule. → 13.11.4 "Assigning units to a schedule"



		Description	Description/References
Emblion v		View area	View of the selected schedule and the assigned units.
P1 P2	× ×		Confirm and Cancel
R4 R5	×		→ 13.11.4 "Assigning units to a schedule"
Room 1 Room 2	×		→ 13.11.5 "Deleting a unit from a time program"
		Clear group	Delete all units from a schedule.
Clear group			→ 13.11.6 "Delete all units from the schedule"

13.11.2 Overview of units and groups

The **Assign units** page in the **Select units** area contains an overview of the units, arranged into 2 categories:

- All units: all units that have been detected by the system and created.
- If groups have been created, the units assigned to these groups will be displayed under these groups.

To show the units in the 2 categories:

► Select ✓.
Units are displayed.



- → 13.11.1 "Overview Assign units"
- → 11 "Group editor"

13.11.3 Selecting a schedule

To select a schedule:

- ► Select Time program selection dropdown list.
- Select schedule.

The selected schedule appears in the View area.



→ 13.11.1 "Overview Assign units"

13.11.4 Assigning units to a schedule

To assign units to a schedule:

- ► Select schedule to which you wish to assign the units.
- ► Expand groups and/or **All units**.
- Select of the units you wish to assign to the schedule.
 - appears. Units are selected.
 - \rightarrow appears.
- ▶ Select →.

-or

- Drag-and-drop each unit individually into the schedule in the View area.
- ► Select Confirm.

Units are assigned to the the schedule.

To cancel the operation:

► Select Cancel.



- → 13.11.2 "Overview of units and groups"
- → 13.11.3 "Selecting a schedule"

13.11.5 Deleting a unit from a time program

To delete a unit from a time program:

- ► Select time program from which you wish to delete a unit.
- ► Select × of the unit in the View area.
- ► Confirm choice.

The unit is deleted from the time program.



- → 13.11.3 "Selecting a schedule"
- → 13.11.1 "Overview Assign units"

13.11.6 Delete all units from the schedule

To delete all units from a schedule at the same time:

- ► Select the schedule containing all units you wish to delete.
- Select Clear group.

All units are deleted from the schedule.

► Select Confirm.

There are no units assigned to the schedule.

To cancel the operation:

► Select Cancel.



- → 13.11.3 "Selecting a schedule"
- → 13.11.1 "Overview Assign units"

13.11.7 Changing the name of a unit

To change the name of a unit:

- ► Expand the category/group to which the units to be edited belong to display the units in the **Select units** area.
- ► Select _ to the right of the unit in the **Select units** area. The **Rename unit** dialogue box appears.
- ► Enter new name of the unit in the field.
- ► Select Confirm.

The name of the unit has changed.

To cancel the operation:

► Select Cancel.

13.11.8 Closing Assigning units

To close the **Assign units** page and return to the **Schedules** page:



→ 7.2 "Header"

13.12 Activating time programs

Several time programs can be activated only if the assigned units are not shared by those time programs.

To activate a time program:

 Select _____ to the right of the time program in the Schedules area of the sidebar.



Time program is activated.





The following can be set via the **Calendar** page: time periods where the time program is active If no time periods are defined on the **Calendar** page, the time program is continuously active.



- → 13.1 "Overview Schedules"
- → 14 "Calendar"
- → 14.8 "Defining periods for time programs"

13.13 Calling up the Calendar page

To call up the **Schedules** page via the **Calendar** page:

► Select in the bottom part of the Schedules sidebar. The **Calendar** page appears.



- → 13.1 "Overview Schedules"
- → 14 "Calendar"

13.14 Exiting the Schedules

To end editing of the schedule on the **Schedules** page:



The activated schedules remain active after ending editing of the schedule.



- → 7.2 "Header"
- → 7.1 "Dashboard"
- → 13.12 "Activating time programs"

14 Calendar

Periods during which the created time programs are to be active are defined on the **Calendar** page.

To call up the Calendar page:


-or-

► Page Schedules > ☐ The Calendar page appears.



- → 7.1 "Dashboard"
- → 7.2 "Header"
- → 13 "Schedules"

14.1 Overview Calendar





	Designation	Description/references
≡ ໖ ๖	Header	 Navigation element, at the top edge of the screen on every page → 7.2 "Header" → 14.9 "Ending the Calendar"
ii 29°C 20.03.2019 1:05 pm	Footer	 Display of outdoor temperature, date and time → 7.4 "Footer"
Schedules	Schedules sidebar	 Selection of created time programs Access to Assign units and Schedules. → 14.3 "Select or deselect schedules" → 14.5 "Calling up the Schedules page"
«		 Hide sidebar. → 13.10.2 "Displaying/hiding the sidebar"
<u>•</u>		Call up the Schedules page. → 14.5 "Calling up the Schedules page"
Maj. 19 Maj.	View area	 View of selected time programs in the calendar view. Select month and year display. Access definition of time periods. → 14.3 "Select or deselect schedules" → 14.7 "Select a day or a period" → 14.6 "Changing the calendar view" → 14.8 "Defining periods for time programs"
2019 A 2017 2018 2018 2010 2010 2014 2002	Month and year dropdown list	Select month and year display. → 14.6 "Changing the calendar view"
Set the period	Set the period	 Define periods when time programs are active. → 14.8 "Defining periods for time programs"

14.2 Displaying/hiding the sidebar

To hide the sidebar:

► Select ⟨⟨. Sidebar is hidden.

To display the sidebar:

► Select ≫. Sidebar is displayed.

14.3 Select or deselect schedules

All time programs created on the **Schedules** page are displayed in the Schedules sidebar of the **Calendar** page.

14.3.1 Selecting one or several schedules

To select one or more schedules for viewing or editing:

► Select next to the schedules.

appears. The schedules are selected and appear in different colours in the View area of the calendar.



Up to 4 schedules can be displayed simultaneously in the Area view of the calendar.



- → 14.1 "Overview Calendar"
- → 14.4 "Displaying more than 4 schedules"

14.3.2 Deselecting schedules

To deselect selected schedules:

► Select ✓ to uncheck it.

appears. The schedule has been deselected and is no longer displayed in the View area of the calendar.



- → 14.1 "Overview Calendar"
- → 14.3.1 "Selecting one or several schedules"

14.4 Displaying more than 4 schedules

To display more than 4 selected schedules:

- ► Select more than 4 schedules in the **Schedules** sidebar.
- appears in the View area next to the days of the calendar view.
- Select the symbol of the day for which you wish to display all selected schedules.

The **Active schedules** window appears and displays the active schedules for the relevant day.

To close the **Active schedules** window:

► Select Confirm.



- → 14.1 "Overview Calendar"
- → 14.3.1 "Selecting one or several schedules"



14.5 Calling up the Schedules page

To call up the **Schedules** page from the **Calendar** page (e.g. to create additional time programs):

► Select in the bottom part of the Schedules sidebar. The **Schedules** page appears.



- → 14.1 "Overview Calendar"
- → 13 "Schedules"

14.6 Changing the calendar view

To display a different month or year in the View area of the calendar view:

- ► Select the month via the Month dropdown list.
- Select the year via the Year dropdown list.
 The selected month or year appears in the calendar view.

-or-

► Select ↑ or ↓.

The calendar view shifts up a week or down a week.



→ 14.1 "Overview Calendar"

14.7 Select a day or a period

To select a single day:

► Select day in the calendar view in the View area. The tile of the day selected appears blue.

To select a period:

 Select the first and last day of the desired period in the calendar overview in the View area.

The tile of the period selected appears blue.



Periods can be changed again via Set the period.



- → 14.1 "Overview Calendar"
- → 14.8 "Defining periods for time programs"

14.8 Defining periods for time programs

The periods during which time programs that have been created are active can be defined.

If periods are not defined, the activated time program is continuously active (default setting).



A period can only be defined for one selected time program, and not for several time programs at once.

To define a period for a time program:

- ► Select an existing time program in the Schedules sidebar.
- ► Select a day or a period in the calendar overview.
- ▶ Select Set the period.

The **Define period for** window (name of the time program) is displayed. The day or period previously selected is set.

To change the day or period:

Adjust the date in the Set the period area by dragging up or down.
 The day or period for the time program has been modified.

To define whether the period occurs only once or repeats every year:

Select Unique from the dropdown list.

-or-

► Select **Yearly** from the dropdown list. **Repeat** (once or annually) of the period is defined.

-or-

To always run the time programs:

► Select **Always** from the dropdown list.

To apply the settings:

▶ Select Confirm.

The defined period is displayed in the colour of the time program in the calendar overview in the View area.

To cancel the operation:

► Select Cancel.



- → 14.1 "Overview Calendar"
- → 13 "Schedules"

14.9 Ending the Calendar

To exit the Calendar page:



- → 7.2 "Header"
- → 7.1 "Dashboard"

15 Energy management


To call up the **Energy management** page:



→ 7.2 "Header"



Overview Energy management



The following setting options are available:


Designation	Description/references	
Output limitation	Set output restriction for the refrigerant systems and the assigned units.	
	→ 15.1 "Output limitation"	
Energy meter manager	Create, integrate and configure energy meters.	
	→ 15.2 "Energy meter editor"	
Energy meter overview	Retrieve information about the energy meters.	
	→ 15.3 "Energy meter monitor"	
Tenant Management	Assign indoor units to tenants.	
	→ 15.4 "Tenant management"	
Energy distribution	Turn energy distribution on and off for each refrigerant system.	
	→ 15.5 "Energy distribution"	
Energy report	Generate energy report and save to USB stick.	
	→ 15.6 "Energy report"	

15.1 Output limitation

The **Output limitation** page can be used to set an output restriction for the refrigerant systems and the assigned units.


By adjusting the compressor frequency on the outdoor unit, the maximum electrical power input of the VRF system can be gradually reduced (from 100% to 40% of the maximum output).

To call up the **Output limitation** page:





15.1.1 Overview Output limitation



	Description	Description/References
≡ ७ ๖	Header	 Navigation element, on every page at the top edge of the screen → 7.2 "Header" → 15.1.6 "Exiting the Output limitation"
#∆ 29°C 20.03.2019 1:05 pm	Footer	 Display of outside temperature, date and time → 7.4 "Footer"
Output limitation 《	Sidebar	 Ports sidebar Once at least one refrigerant system has been selected, the Output limitation sidebar appears. → 15.1.3 "Selecting port" → 15.1.5 "Setting an output restriction"
«		 Hide sidebar. → 13.10.2 "Displaying/hiding the sidebar"
Met Summer Met Met Summer Met Summer	View area	View and selection of refrigerant systems → 15.1.4 "Selecting and deselecting refrigerant systems"
Select all	Select all or Select none	 Select all refrigerant systems. Once all refrigerant systems have been selected, the Select none button appears via which all refrigerant systems can be deselected. → 15.1.4 "Selecting and deselecting refrigerant systems"

15.1.2 Displaying/hiding the sidebar

To hide the sidebar:

► Select <<... Sidebar is hidden.

To display the sidebar:

► Select ≫. Sidebar is displayed.

15.1.3 Selecting port

A port is a connection for an XYE cable. The central controller itself has an XYE port, the AC EXP expansion card offers 3 additional ports.



To select a port:

Select port in the **Ports** sidebar. The port appears highlighted in blue. The refrigerant systems assigned to the port are displayed in the View area.



- → 15.1.1 "Overview Output limitation"
- → 16.2 "System structure"
- → 15.1.5 "Setting an output restriction"

15.1.4 Selecting and deselecting refrigerant systems

Refrigerant systems must have been selected in the View area before an output restriction can be set for refrigerant systems.



→ 15.1.1 "Overview Output limitation"

Selecting one or several refrigerant systems

To select one or several refrigerant systems for editing:

► Select the corresponding for the refrigerant systems you wish to edit in the View area.

appears. Refrigerant systems are selected. The **Output limitation** sidebar appears.



- → 15.1.1 "Overview Output limitation"
- → 15.1.5 "Setting an output restriction"

Selecting all refrigerant systems

To select all refrigerant systems for editing:

► Select Select all.

✓ appears. All refrigerant systems are selected. The Output limitation sidebar appears.



- → 15.1.1 "Overview Output limitation"
- → 15.1.5 "Setting an output restriction"

Deselecting refrigerant systems

To deselect selected refrigerant systems:

► Select ✓ to uncheck it.

appears. The refrigerant system is deselected.

To deselect all selected refrigerant systems:

Select Select none.

appears. Refrigerant systems are deselected.

15.1.5 Setting an output restriction

To call up the **Output limitation** sidebar:

 Select at least one refrigerant system whose output you wish to adjust.

The **Output limitation** sidebar appears on the left hand edge of the screen on the **Output limitation** page.

An output restriction can be set for every refrigerant system in the following 7 stages:

- 100 % full load
- Max. 90 %
- Max. 80 %
- Max. 70 %
- Max. 60 %
- Max. 50 %
- Max. 40 %

To set and apply the output restriction for selected refrigerant systems:

-or-

 Drag the control dial in the — direction, or touch the semicircle directly at any given point until the required stage (value displayed in the centre) is reached.

Alternatively, the output restriction can also be adjusted as follows:

► Select — or — until the required stage is reached.

The output restriction stage is displayed for the selected refrigerant systems in the View area on the **Output limitation** page.



- → 15.1.1 "Overview Output limitation"
- → 15.1.4 "Selecting and deselecting refrigerant systems"

15.1.6 Exiting the Output limitation

To close the settings for the output restriction on the **Output limitation** page:

▶ Select header > n.
Dashboard appears.



- → 7.2 "Header"
- → 7.1 "Dashboard"

15.2 Energy meter editor

Energy meters can be added, adjusted, units assigned and replaced/removed via the **Energy meter manager** page.

To call up the **Energy meter manager** page:


Energy meter manager appears.



→ 7.2 "Header"



15.2.1 Overview, energy meter editor



	Designation	Description/references
≡ ⋒ ⇒	Header	Navigation element, at the top edge of the screen on every page → 7.2 "Header" → 15.2.6 "Close the Energy meter manager"
I	Footer	 Display of outdoor temperature, date and time → 7.4 "Footer"
Energy meter + Baudrate 9600 D ADB 👚 D	Area Energy meter	 Create an energy meter. Display of all energy meters created Change the baud rate. → 15.2.2 "Create an energy meter" → 15.2.3 "Setting the energy meter"
+		 Create an energy meter. → 15.2.2 "Create an energy meter"
萱		Delete the energy meter.
_Ø		 Rename the energy meter. Change the baud rate. → 15.2.2 "Create an energy meter" → 15.2.3 "Setting the energy meter"
Ceep noter settings Large noter mapping Address 3 Type ABB 82 Check connection	View area	 Access to the Energy meter settings area and Energy meter mapping area → 15.2.3 "Setting the energy meter" → 15.2.4 "Assign the energy meter units"
Energy meter settings	Area Energy meter settings	→ 15.2.3 "Setting the energy meter"
Energy meter mapping	Area Energy meter mapping	→ 15.2.4 "Assign the energy meter units"



	Designation	Description/references		
Type ABB 82	Dropdown list Type	Select the energy meter type.		
Type ABB 82		→ 15.2.3 "Setting the energy meter"		
Check connection	Display Check connection	Check the connection.		
Check connection		→ 15.2.3 "Setting the energy meter"		
	Field Address	Enter Modbus address.		
Address 3		→ 15.2.3 "Setting the energy meter"		
Baudrate 9600	Change the baud rate	Change the baud rate.		
Daddrate 5000 _y		→ 15.2.3 "Setting the energy meter"		

15.2.2 Create an energy meter

The central remote control of Bosch supports the following Modbus/RTU energy meter:

- ABB B2
- · Entes MPR-2
- Schneider Electric iEM3000
- Siemens PAC 1600
- Siemens PAC 2200

To create an energy meter:

- ► Select + in area Energy meter.
- Select an energy meter from the drop-down list in the area Energy meter settings. All energy meters in the system are displayed in the drop-down list.
- Name the energy meter.
 The energy meter created appears in the area Energy Meter.



→ 15.2.1 "Overview, energy meter editor"

15.2.3 Setting the energy meter

The view area can be used to set a previously created energy meter via the Energy meter settings area.

15.2.4 Assign the energy meter units

Units can be assigned to an energy meter via the area Energy meter mapping in the view area.

To set an energy meter:

- ► In the area Energy meter , select an energy meter that has been created.
- ► In the area view, select the area Energy meter settings.
- ► Enter the Modbus address in the Address field.
- Select the energy meter type from the drop-down list Type. The display Check connection shows whether there is a connection to the respective energy meter and whether the data can be read.



→ 15.2.1 "Overview, energy meter editor"

If necessary, the baud rate of the system can be changed.


To change the baud rate:

- Select ____ in the energy meter area next to baud rate.
- ► Change the baud rate.



Important: if the baud rate has been changed, check the connection of the respective energy meters again.





To allocate an energy meter to units:

- ► In the area Energy meter , select an energy meter that has been created.
- In the area selection, select the area Energy meter mapping. The view Not assigned units and Assigned units appear.
- In the list Not assigned units, select the units that have to be allocated to the energy meter and pull to the area Assigned units by means of drag & drop.

The units are allocated to the energy meter.



A maximum of 3 units can be allocated to an energy meter if they are within a cascade.



One unit can only be allocated to one energy meter at a time. It is not possible to allocated a unit to several energy meters.



- → 15.2.1 "Overview, energy meter editor"
- → 15.2.2 "Create an energy meter"

15.2.5 Replacing/removing the energy meters

To replace or remove an energy meter in a refrigerant system:

- Switch off the energy distribution for the refrigerant system concerned.
- Remove the energy meter and replace it with a new energy meter (meter reading at 0).
- Set new energy meter if it is not of the same type as the old energy meter or has a different Modbus address.
- Switch on the energy distribution for the respective refrigerant system again.



- → 15.2.1 "Overview, energy meter editor"
- → 15.5 "Energy distribution"
- → 15.2.3 "Setting the energy meter"

15.2.6 Close the Energy meter manager

To close the **Energy meter manager** page:



- → 7.2 "Header"
- → 7.1 "Dashboard"

15.3 Energy meter monitor

Information on the energy meters connected can be called up via the **Energy meter overview** page.


To call up the **Energy meter overview** page:



→ 7.2 "Header"



15.3.1 Overview, energy meter monitor



The **Energy meter overview** page displays detailed information about the energy meters connected. The values are displayed in real time and serve for the analysis of the respective energy meter.

15.4 Tenant management


Tenants can be created and indoor units allocated on the **Tenant Management** page.

To call up the $\underline{\textbf{Ten}} \\ \textbf{ant Management}$ page:





15.4.1 Overview, tenant management



The following settings can be made for on the **Tenant Management** page:

- · Set the tenant.
- Allocate a tenant from a list or group of indoor units.
- Subsequently rename a tenant.
- · Delete a tenant from the list.
- · Subsequently add or delete indoor units.



One indoor unit can only be allocated to one tenant at a time.

15.5 Energy distribution

The energy distribution can be switched on and off for each refrigerant system via the **Energy distribution** page.


To call up the **Energy distribution** page:



→ 7.2 "Header"



15.5.1 Switch the energy distribution on / off



The software for the energy distribution can be switch on or off individually using the dialogue for each refrigerant system.

The software calculates the energy consumption of the outdoor units and displays a distribution of the energy consumption of the indoor units.

The calculation for the energy distribution can be switch on or off individually using the dialogue for each refrigerant system.



After changing the time zone, it is necessary to restart the ACC MT central controller, otherwise errors will occur in the calculation of the power consumption.



If energy distribution is active in a refrigerant system, then changing or editing the allocated energy meter via the energy meter editor is not permitted.



It is essential that the NTP is configured.



A MicroSDX/SDXC card with at least 4 GB memory is required for operation of the energy meter.

Recommended: 8 GB High Reliability

Note:

If the energy distribution for a refrigerant system cannot be activated, ensure the following points:

· An energy meter is allocated to each outdoor unit.

- · A connection has been established to all assigned energy meters.
- · There are no faults in the system.



- → 15.2.3 "Setting the energy meter"
- → 20 "Troubleshooting"

15.6 Energy report

A report on the energy consumption of the outdoor units, converted to the connected indoor units, can be generated for a selected period of time and saved on a USB stick connected to the unit via the **Energy report** page.

To call up the Energy report page:




→ 7.2 "Header"



15.6.1 Energy report

Basic system report



i

The selection of the report refers to all refrigerant systems connected (only applicable for Basic system report).

To create a Basic system report:

- ► In the area **Report**, select **Basic**.


 The selection Basic system report appears.
- ► Set Period.

The period that can be selected for a report is maximum 24 months.

► Select Create Report.



Advanced system report



To create an advanced system report:

- ► In the area **Report**, select **Advanced**.

 The selection Advanced system report appears.
- ► Via the **System selection** dropdown list, select the refrigerant system for which the report should be created.
- Select Report typeDaily or Hourly.
- ► Set Period.

Daily report: maximum selectable period 2 years. Hourly report: maximum selectable period 1 year.

► Select Create Report.



Important: monthly data are automatically deleted after 10 years. Daily and hourly data are automatically deleted after 2 years.

16 Diagnosis

16.1 Fault and event history

To call up the **Fault and event history** page:

► Header > == > V_B Diagnosis > Fault and event history

-or-

► If faults are present, the symbol ! is displayed in the header. ! select.

-or-

► If Warnings are present, the symbol is displayed in the header.
↑ select.

The **Fault and event history** page appears.



→ 7.2 "Header"

Faults, warnings and events of the VRF system or the central controller are displayed on the **Fault and event history** page in a list view with several columns. Faults, warnings and events are each listed for the central controller, the outdoor unit and the indoor unit in separate higher-level tabs.

In the list, currently pending as well as historic faults, warnings and events are displayed:

- The current status of the entries is displayed in the first column. As standard, the entries currently pending are displayed first (click on column header to display solved first), sorted according to their time of occurrence (new events at the top in the list).
- The device affected is displayed in the second column.
- The fault or the event are described in the third column together with the respective fault code, if applicable.
- In the last column, the time of the last update of the list entry is displayed. In the case of currently pending entries, this is the time of occurrence; in the case of resolved list entries, this is the time at which the fault or event was resolved.

To empty the fault and event history:

➤ Select **Clear all**.
Fault and event history has been emptied.

i

→ 20 "Troubleshooting"

16.2 System structure

To call up the page **System structure**:




→ 7.2 "Header"



16.2.1 Overview of system structure



The overview displays the **System structure** page once the VRF system has been scanned (e.g. after exiting the configuration wizard starting a new system scan).



	Description	Description/references	
	Header	Navigation element, at the top edge of the screen on every page	
= 6 5		→ 7.2 "Header"	
_ ш ೨		→ 16.2.7 "Exiting the System structure"	
	Footer	Display of outdoor temperature, date and time	
Il 29°C 20.03.2019 1:05 pm		→ 7.4 "Footer"	
[Port.1]	Select area sidebar	Selection of ports	
Refrigerant system 0 Refrigerant system 1		Display and selection of the refrigerant systems	
Refrigerant system 2 %		Call up measurements and parameters (system monitor) of the	
Refrigerant system 4		refrigerant systems.	
		→ 16.2.2 "Selecting port"	
		→ 16.2.3 "Selecting refrigerant system"	
	Add unit	Manually add unit (IDU) to a refrigerant system.	
Add unit		→ 16.2.6 "Add unit"	
	Scan VRF system	Scan VRF system again.	
Scan VRF system		→ 16.2.4 "Scan VRF system (System scan)"	
	View area	View of selected refrigerant and the assigned units	
Refrigerant system 1 ODUS Units		Call up measurements and parameters (system monitor) of the units.	
© 000-0100 Marier		→ 16.2.3 "Selecting refrigerant system"	
B countral state © COUNTRY STATE OF THE COUNTRY STA		→ 16.3 "System monitor"	
⊕ 0004246 Maner		→ "Overview of symbols for unit types"	
-		Overview of Symbols for unit types	



Description Description/references		Description/references
()		Access System monitor page.
N.		→ 16.3 "System monitor"
_		Delete unit (IDU) manually from a refrigerant system.
一		→ 16.2.5 "Deleting unit"

16.2.2 Selecting port

Up to 4 ports and the refrigerant systems assigned to these ports can be displayed in the Select area on the **System structure** page.

A port is a connection for an XYE cable. The central controller itself has an XYE port, the AC EXP expansion card offers 3 additional ports.

To select a port:

- ► Select dropdown list in the Select area.
- Select port.

The port name is displayed. The refrigerant systems assigned to the port are displayed in the Select area where they can be selected.



- → 16.2.1 "Overview of system structure"
- → 16.2.3 "Selecting refrigerant system"

16.2.3 Selecting refrigerant system

8 refrigerant systems can be assigned to one port. After selecting the port, the refrigerant system assigned is displayed in the Select area.



Several refrigerant systems can be selected at the same time.

To select a refrigerant system:

▶ select the refrigerant system whose unit should be displayed.
 ✓ appears. The units (IDU and ODU) of the refrigerant system selected appear in the View area of the **System structure** page.

A refrigerant system is either assigned to an ODU or a cascade from an ODU (master) with up to 2 lower level ODUs (slave). Up to 64 units (IDUs, ERV, AHU KITS) can be assigned to each port. These can be distributed to different refrigerant systems.



- → 16.2.1 "Overview of system structure"
- → 16.2.2 "Selecting port"
- → 16.2.5 "Deleting unit"
- → 16.3 "System monitor"

16.2.4 Scan VRF system (System scan)

It may be necessary to scan the VRF system again, after assigning new addresses or making changes to the system structure, for example.

The system scan can also be started via the main menu:



If a system scan is carried out again, **all** addresses already entered, settings made for the units and groups, time programs, etc. that have been created are **deleted**. When making small changes to the system structure, we recommend adding or deleting units manually.

To scan the VRF system again:

Select Scan VRF system.

The Scan VRF system dialogue box appears.

► Select Syst. scan.

The system scan starts automatically. A progress bar appears for the duration of the scan. Once the system scan is complete, all detected units are available for operation via the central controller. The

System structure page appears. All devices detected by the system scan are displayed on this page.

To cancel the operation:

► Select Cancel.



- → "Abbreviations and concept application"
- → 16.2.1 "Overview of system structure"
- → 16.2.6 "Add unit"
- → 16.2.5 "Deleting unit"
- → 16.2.3 "Selecting refrigerant system"
- → 7.3 "Initial Menu"

16.2.5 Deleting unit

To delete a unit (IDU) manually from the refrigerant system, instead of via the system scan:

- ► Select the refrigerant system from which you wish to delete a unit.
- Select to the right of the unit in the View area on the System structure page.

The **Delete unit** dialogue box appears.

Select Confirm.

The unit is deleted from the refrigerant system.

To cancel the operation:

► Select Cancel.



- → 16.2.1 "Overview of system structure"
- → 16.2.3 "Selecting refrigerant system"

16.2.6 Add unit

To manually add a refrigerant system to a unit (IDU) instead if via the system scan:

- ► select Add unit on page System structure.
 - The Add unit dialogue box appears.
- ► Select port via the**Select port** dropdown list.
- Select refrigerant system via the Select refrigerant system dropdown list.
- ▶ Select the **Address** of the unit via the dropdown list.
- ► Select Confirm.

The refrigeration system has been added to the unit.

To cancel the operation:

► Select Cancel.



→ 16.2.1 "Overview of system structure"

16.2.7 Exiting the System structure

To close the page **System structure**:

Select header >

 Dashboard appears.





- → 7.2 "Header"
- → 7.1 "Dashboard"

16.3 System monitor

Via the System monitor page, the measured values as well as the refrigerant systems, outdoor units and all units (IDU, MDCI¹⁾, ERV, AHU KIT, AF-HB) can be viewed.

1) Function depends on which version of the central controller is used.

To call up the System monitor page:


To call up via the System monitor page the **System structure** page:

- ► Selecting refrigerant system.
- ► Un Select to the right of the refrigerant system in the Select area. The System monitor page appears.



- → 7.2 "Header"
- → 16.2.1 "Overview of system structure"
- → 16.2.3 "Selecting refrigerant system"

16.3.1 Overview of system monitor



	Description	Description/references			
	Header	Navigation element, at the top edge of the screen on every page			
≡ ⋒ 5		→ 7.2 "Header"→ 16.3.6 "Exiting the System monitor"			
	Footer	Display of outdoor temperature, date and time			
II 29°C 20.03.2019 1:05 pm		→ 7.4 "Footer"			
nor v (Maparity, v Priliv	Selection area	 Select port via dropdown list. Select refrigerant system via the dropdown list. Select refrigerant system or units whose measurements and parameters are to be displayed via the dropdown list. → 16.2.2 "Selecting port" → 16.2.3 "Selecting refrigerant system" → 16.3.4 "Selecting display" 			



	Description Description/references				
	Address [-]		View area, left	Display of measurements/parameter names.	
	Name Indoor unit type			→ 16.3.5 "Overview of measurements and parameters"	
	Operating mode				
	Set temperature [°C]				
	DC fan speed				
	Room temperature [* T2 [*C]	21			
	T2A [*C]				
	T2B [°C]				
9 10 143-09 IDU-03 IC A/-4C	11 12 9-90 100-09-11 100-09-12 M-W M-4C	13 14 10U-03-13 10U-03-14 F-04 MF-0C	View area, centre	Display of measurements and parameters of the selected refrigeran systems or units.	
(Only) Dry mor	de Cooling Fan (Only) mode Mode	an (Only) Cooling fode mode			
3	23 23 5 2	9 20		→ 16.3.5 "Overview of measurements and parameters"	
21	23 23	1 20			
-1	-5 -6	4			
-10	6 0	-7			

16.3.2 Selecting port

To display the parameters of a refrigerant system or corresponding units on the **System monitor** page, a port must initially be selected.

A port is a connection for an XYE cable. The central controller itself has an XYE port, the AC EXP expansion card offers 3 additional ports.

To select a port:

Select port via Port dropdown list in the Selection area.
 The port is selected and the assigned refrigerant systems can be selected.



- → 16.3.1 "Overview of system monitor"
- → 16.3.3 "Selecting refrigerant system"

16.3.3 Selecting refrigerant system

Once the port has been selected, the refrigerant systems assigned to the port can be selected.

To select a refrigerant system:

Select the refrigerant system to be displayed from the Select refrigerant system dropdown list in the Selection area. Refrigerant system is selected. The parameters of the selected refrigerant system and corresponding units are displayed in the View area.



- → 16.3.1 "Overview of system monitor"
- → 16.3.2 "Selecting port"

16.3.4 Selecting display

After selecting the port and the refrigerant system, the refrigerant system or the assigned units can be selected in order to view their parameters.

To select the parameters of the refrigerant system:

Select System in the Selection area via the dropdown list. The parameters of the refrigerant system are displayed in the View area. The selection is displayed in blue.

To select the parameters of the assigned outdoor units (ODU):

Select Outdoor unit in the Selection area.
 The parameters of the outdoor units are displayed in the View area.
 The selection is displayed in blue.

To select the parameters of the assigned indoor units (IDU):

Select IDU in the Selection area.
 The parameters of the indoor units are displayed in the View area.
 The selection is displayed in blue.

To select the parameters of the assigned ventilation units (ERV):

► Select **ERV** in the Selection area.

The parameters of the ERV ventilation units are displayed in the View area. The selection is displayed in blue.

To select parameters of the assigned DX-AHU connection sets AHU KIT:

► Select **AHU** in the Selection area.

The parameters of the DX-AHU connection kit AHU KIT are displayed in the View area. The selection is displayed in blue.



- → 16.3.1 "Overview of system monitor"
- → 16.3.5 "Overview of measurements and parameters"

16.3.5 Overview of measurements and parameters

Once the selection has been made, the measurement/parameter names appear in the View left area and the corresponding measurements and parameters appear in the View centre area.



→ 16.3.1 "Overview of system monitor"

16.3.6 Exiting the System monitor

To close the page **System monitor**:



- → 7.2 "Header"
- → 7.1 "Dashboard"

16.4 Digital input



If the refrigerant system receives an emergency off signal (**Emergency stop**), e. g. from a connected smoke alarm, then all appliances connected are automatically switched off in the ACC MT central controller and the controllers are blocked.


The function **Emergency stop** can be switched on and off via the **Digital input** page.

To call up the **Digital input** page:





→ 7.2 "Header"



To activate the **Emergency stop** function:



The display changes from Off to On.

The **Emergency stop** function is active.



Notice: if the **Emergency stop** function is not activated, the refrigerant system can continue to be operated even in the event of a pending emergency off signal.




Notice: the digital input signal must be provided to the ACC MT central controller in order to use the emergency off function. If no digital input signal is provided, the emergency off function does not function even though it is activated.

Emergency stop

If the **Emergency stop** function is activated, in the event of a pending emergency, the operation of the ACC MT central controller is blocked by the **Emergency stop signal received** message window.

As long as the emergency off signal is present, it is not possible to operate the refrigerant system.





17 System configuration

17.1 Floor plan editor

i

→ 12 "Floor plans/Floor plan editor"

17.2 Group editor



→ 11 "Group editor"

17.3 Set up system



- → 16.2 "System structure"
- → 16.2.4 "Scan VRF system (System scan)"

The following setting options are available:

18 Controller settings

To call up the page **Controller settings**:

- ► Dashboard > ۞ Controller settings
- -or-



- → 7.2 "Header"
- → 7.1 "Dashboard"

Overview Controller settings

The following setting options are available:		
Designation	Description/references	
User management	View, create and delete users.	
	Change password and make further settings.	
	→ 18.1 "User management"	
Network settings • Configure LAN port.		
	Make Network Settings.	
	Activate PC interface.	
	→ 18.2 "Network settings"	
Screen settings • Make screen settings.		
	→ 18.3 "Screen settings"	
Language, date and time	Change settings for time zone, date, time and language.	
	→ 18.4 "Language, date and time"	



Designation	Description/references	
E-mail manager	Set up e-mail warnings in the event of faults.	
	→ 18.5 "E-mail manager"	
Device & Updates	Restore factory settings on central controller.	
	→ 18.6.1 "Resetting all settings"	
	Restart central controller.	
	→ 18.6.2 "Restarting"	
	Save user-specific settings on the USB stick and restore.	
	→ 18.6.3 "Backing up and restoring settings"	
	Install the software update from USB stick	
	→ 18.6.4 "Software update from USB stick"	

18.1 User management

Users can be viewed, created, edited or deleted by an administrator via the **User management** page.

To call up the page **User management**:

► Dashboard > ۞ Controller settings > User management



- → 7.2 "Header"
- → 7.1 "Dashboard"

Overview User management

Description	Description/References
	Header: navigation element, on every page at the top edge of the screen
≡ 🙆 与	→ 7.2 "Header"
	→ 18.1.5 "Closing user management"
User overview	Display all created users
Add user	Add new user.
	→ 18.1.2 "Add user"
A	Change username, user role and user password.
_6/	→ 18.1.4 "Changing user data"
	Delete user.
	→ 18.1.3 "Deleting users"

18.1.1 User roles

The **Operator**, **Expert** as well as **Administrator** user roles have different rights.

The following rights are assigned to the corresponding user roles:

Description/Link	User	Expert	Administrator
→ 9.1 "Settings"	✓	✓	✓
→ 10 "Lock Manager"	-	√ 1)	✓
→ 11 "Group editor"	-	√ 1)	✓
→ 12.2 "Floor plan editor"	-	√ 1)	✓
→ 13 "Schedules"	_2)	√ 1)	✓
→ 14 "Calendar"	_2)	√ 1)	✓
→ 15 "Energy management"	-	-	✓
→ 16.1 "Fault and event history"	_2)	_2)	✓
→ 16.2 "System structure"	_	_2)	✓
→ 16.2.4 "Scan VRF system (System scan)"	-	-	✓
→ 16.3 "System monitor"	-	√ 1)	✓
→ 16.4 "Digital input"	-	√ 1)	✓
→ 18.1 "User management"	_3)	-3)	✓
→ 18.2 "Network settings"	-	√ 1)	✓
→ 18.4 "Language, date and time"	-	√ 1)	✓
→ 18.6 "Device and updates"	-	√ 1)	✓
→ 18.6.3 "Backing up and restoring settings"	-	√ 1)	✓



Description/Link	User	Expert	Administrator
→ 18.5 "E-mail manager"	-	√ 1)	✓
→ 18.6.1 "Resetting all settings"	-	-	✓

- 1) Only if all unit access is given
- 2) Only view of accessible Units available (no changes possible)
- 3) User can view and change only the settings of current user

Table 2 Rights of all user roles

18.1.2 Add user

Only an administrator can add new users.



Personal data and settings are stored locally on the central controller and can be viewed by other users if required.

To add a new user:

▶ Select Add user.

The form for adding a new user appears.

User name

The username must be no more than 30 characters in length. An individual username must always be created that does not allow conclusions to be drawn about the identity of the person.

To create a username:

► Enter username in the **User name** field.

User role

To assign a role to the user:

► Select **User role** from the dropdown list.

Password

To create a password:

- ► Select next to Password required.
 - appears. The password entry fields appear.
- ► Enter password in the **Password** field.
- ► Confirm password in the **Confirm password** field.

The password function can also be deactivated. This function is only available to users with the role of User.

To deactivate the password function:

- ► Select next to Password required.
 - appears. Password function is deactivated.

Automatic logoff

If the **Automatic logoff** function is activated, a logged-in user is automatically logged out once a certain period of inactivity has elapsed. This function is only available to users with the roles User and Expert.

To activate the **Automatic logoff** function:

- ► Select next to Automatic logoff.
 - appears. Function is activated.

Access to all units

If the **Access to all units** is activated for a user, all units can be accessed.



An administrator automatically has access to all units. Depending on the application, it must be considered whether or not users with the User and Expert user roles should be granted access to all units.

To activate the **Access to all units** function:

► Select next to Access to all units.

appears. Function is activated. If groups have already been created, these can no longer be selected.



To assign groups to the user, the **Access to all units** function must be deactivated ().

By being assigned to a group, a user gains access to the units assigned to the group. Groups can be created on the **Group editor** page.

Once groups have been created, they appear under **Access to** and can be assigned to the user.

To assign groups to the user:

- ► Select of the group to which the user is to have access.
 - ✓ appears. Group is assigned to the user.



If a group is deleted via the **Group editor** page, the users assigned to this group can no longer access the units assigned to this group.

To apply all settings and permanently create a user:

► Select Confirm.

The user has been created and appears under **User overview**.

To cancel the operation:

► Select Cancel.



- → 2 "Data protection notices for the operator"
- → 18.1.1 "User roles"
- → 18.1.4 "Changing user data"
- → 11 "Group editor"

18.1.3 Deleting users

Users in any user role can be deleted under **User overview**.

To delete a user:

- ► Select 🕅.
 - Warning message appears.
- ► Select Confirm.

The user is deleted and no longer appears under User overview.

To cancel the operation:

► Select Cancel.

18.1.4 Changing user data

An administrator can change the user name, user role and password of users in any user role under **User overview**. Every other user can on the other hand change his own password.



If the password input is deactivated, the fields for changing the password are not displayed.

To change the user data:

- ► Select Ø.
 - The fields in which the data can be changed appear.
- ► Enter new user name in the **User name** field.
- ► Change user role via **User role** dropdown list.
- Enter new password in the Password field.



- Enter new password again in the Confirm password field as confirmation.
- Select and deselect groups under Access to to change assignment.
- ► Select Confirm.

The user data is changed. To cancel the operation:

► Select Cancel.



- → 18.1.2 "Add user"
- → 18.1.1 "User roles"

18.1.5 Closing user management

To close the page **User management**:

▶ Select header > n.
Dashboard appears.



- → 7.2 "Header"
- → 7.1 "Dashboard"

18.2 Network settings

Network settings can be made via the **Network settings** page.

To call up the page **Network settings**:

- ► Dashboard > ۞ Controller settings > Network settings -or-
- ► Header > > ∅ Controller settings > Network settings The Network settings page appears.

To make network settings:

- Select network (LAN1/LAN2).
- ► Select next to **DHCP**.

DHCP¹⁾ is activated. Dynamic Host Configuration Protocol (DHCP) enables the network configuration to be assigned to clients by a server. When DHCP is activated, the IP address and additional network configurations are automatically assigned to the central controller.

▶ IP address, Subnet mask, Default gateway, DNS server can only be entered manually if DHCP is not activated. If DHCP is activated these fields are greyed out.

Activate PC interface



The Google Chrome web browser version 83 or higher or the Mozilla Firefox version 68 or higher is required to access the user interface. The current IP-address of the ACC MT is displayed in the input fields if the DHCP function is activated.

The ACC MT uses a self-generated certificate to establish an HTTPS connection. As the external computer does not recognise this certificate, the computer displays a warning the first time the user interface of the ACC MT is accessed. To access the control panel of the ACC MT, the certificate must be accepted manually in the browser.

If **PC interface** is activated, the control panel of the ACC MT can be accessed by entering the IP address of the ACC MT in the browser window of an external computer.

The prerequisite for this is that the external computer is in the same local network.

- ► Activate PC interface at the **PC interface** switch.
- ▶ Select **Confirm** to complete the setup.

-or-

Select Cancel to cancel the setup.

Modbus/TCP

The Modbus/TCP interface enables the ACC MT central controller to read and write data via this protocol.

Separate IP addresses can be assigned for each XYE port.

Modbus/TCP must be activated to start the read/write process.

To activate Modbus/TCP, proceed as follows:



Modbus/TCP Is activated.

18.3 Screen settings

Display settings can be made via the **Screen settings** page.

To call up the **Screen settings** page:

- ► Dashboard > ۞ Controller settings > Screen settings or-



- → 7.2 "Header"
- → 7.1 "Dashboard"

Overview Screen settings

Description	Description/references	
Ambient light sensor	Adapting the brightness of the display according to the ambient light.	
Brightness	Adjusting the brightness of the display.	
	→ 18.3.1 "Adjusting the brightness of the display"	
Switch off after	fter - Adjusting the display switch-off time.	
	→ 18.3.2 "Setting the switch-off time of the display"	

18.3.1 Adjusting the brightness of the display

To adjust the brightness of the display:

 Drag the slider next to **Brightness** to the right or left until the required brightness is reached.
 The brightness of the display has been adjusted.



Recommendation:

to automatically adjust the brightness of the display based on the ambient brightness:

► Switch on the "ALS" (Ambient Light Sensor) function.

¹⁾ The DHCP feature is only available for LAN1.



18.3.2 Setting the switch-off time of the display

The switch-off time is the period of inactivity until the display is switched off.

To adjust the display switch-off time:

 Next to Switch off after, select value (Never, 30min or 60min) via dropdown list.

The switch-off time appears in the field and is applied.

18.4 Language, date and time

The time zone, date, time and language can be modified via the **Language**, **date and time** page.

To call up the page Language, date and time:

- ► Dashboard > ۞ Controller settings > Language, date and time -or-

The **Language**, date and time page appears.

18.4.1 Language

To make settings in the Language area:

Select language from dropdown list. Settings are applied.

18.4.2 Time zone, date and time

To make the settings in the **Time zone**, **date and time** area:

- Select ____ next to Internet time to apply time and date automatically from the Internet.
- ► Select **Time zone** via dropdown list.
- ▶ Adjust **Time** by swiping up or down if **Internet time** is not selected.
- Adjust Date by swiping up or down if Internet time is not selected.
 The settings are applied.

18.5 E-mail manager

If e-mail warnings are to be sent to a maximum of four recipients or recipient lists in the event of faults, this can be specified on the **E-mail manager** page.



Personal data and settings are stored locally on the ACC MT and under some circumstances can be viewed by other users of the ACC MT.


To call up the **E-mail manager** page:



→ "Header overview"

18.5.1 Configuring the Outgoing server settings

The **Outgoing server settings** page contains an input screen form for setting up the e-mail account from which the e-mails are to be sent.



To set up the e-mail account:

- ► Enter e-mail address in the **E-mail** field.
- ► Enter password of the e-mail account in the **Password** field.
- Enter server address in the Server field.
- ► Select encryption from the **Encryption** dropdown list.

To test the settings:

Select Check account settings.
 A window displays the result of the connection test.




→ 18.5.2 "Configuring the E-mail notifications"



18.5.2 Configuring the E-mail notifications

Once the outgoing server has been set up, the option for sending E-Mail warnings in the event of a fault can be activated on the **E-mail notifications** page.



To set up e-mail warnings:

- Activate forwarding of e-mail warnings at the Enable notifications switch.
- Adjust the frequency of the updates in the Sending frequency dropdown list.
- Enter the name of the building where the central controller is located in the Building name field.

The name appears in the subject line of the e-mail warnings.

 Four e-mail recipients at the most are entered in the Recipient addresses area.



→ 18.5.1 "Configuring the Outgoing server settings"

18.6 Device and updates

The **Device & Updates** page can be used to reset and save settings, perform a restart and install software updates from the USB stick.

To call up the **Device & Updates** page:

- ► Dashboard > ۞ Controller settings > Device & Updates -or-



- → 7.2 "Header"
- → 7.1 "Dashboard"
- → 18.1.1 "User roles"

Overview Device & Updates

The following 4 functions can be accessed via the **Device & Updates** page.

Designation	Description/references
Reset all settings → 18.6.1 "Resetting all settings"	
Restart	→ 18.6.2 "Restarting"
Save settings	→ 18.6.3 "Backing up and restoring settings"
SW update from USB stick	→ 18.6.4 "Software update from USB stick"

18.6.1 Resetting all settings



You can restore the factory settings for all user-specific settings and delete the settings for time programs, groups or floor plans on the **Reset all settings** page. The configuration wizard appears on the first start

after the reset. It is possible to restore saved settings.

To call up the Reset all settings page:

► Dashboard > < Controller settings > Device & Updates > Reset all settings

-or-



The Warning dialogue box appears.

To reset all settings to the default settings:

► Select Confirm.

All settings are reset.

To cancel the operation:

▶ Select Cancel.



- → 7.2 "Header"
- → 7.1 "Dashboard"
- → 5.1 "Configuration wizard"
- → 18.6.3 "Backing up and restoring settings"
- → 16.2.4 "Scan VRF system (System scan)"

18.6.2 Restarting



The central controller is restarted via the **Restart** page. In doing so, there is no data loss and all user-specific settings are retained.

To call up the **Restart** page:

► Dashboard > ♦♦ Controller settings > Device & Updates > Restart

-or-

The Warning dialogue box appears.

To restart the central controller:

► Select Confirm.

The central controller is restarted. The **Login** dialogue box appears.

To cancel the operation:

► Select Cancel.



- → 7.2 "Header"
- → 7.1 "Dashboard"
- → 7.5 "Log user in and out"

18.6.3 Backing up and restoring settings

All user-specific settings can be saved to a USB stick via the **Save settings** page. The backup can be used to restore the user-specific settings after resetting all settings.

To call up the **Save settings** page:

► Dashboard > ۞ Controller settings > Device & Updates > Save settings

-or

The **Save settings** page appears.



- → 7.2 "Header"
- → 7.1 "Dashboard"
- → 18.6.1 "Resetting all settings"
- → "Restore settings"

Backing up settings

To back up the user-specific settings to USB stick:

► Select Save settings.

The **Save settings** dialogue box appears and the backup process starts. A further dialogue box appears once the backup is finished.

- ▶ Plug USB stick into the central controller.
- ► Select Ok.

The user-specific settings are backed up on the USB stick.

Restore settings

Backup settings can be restored via the configuration wizard after all settings have been reset, or on a brand new central controller.

To restore the user-specific backup settings:

- Insert USB stick containing the backup settings into the central controller.
- Select Restore settings below the country selection in the configuration wizard.

The dialogue box containing the directory structure of the USB stick appears.

- ► Select file.
- Select Confirm.
- Enter the access data of any administrator account that was saved on the central controller at the time the backup was created. The restoration process starts. Once the settings have been successfully restored, the **Login** dialogue box is displayed.



- → 5.1 "Configuration wizard"
- → 18.6.1 "Resetting all settings"
- → 7.5 "Log user in and out"

18.6.4 Software update from USB stick

All user-specific settings can be saved to a USB stick via the **SW update from USB stick** page. The backup can be used to restore the user-specific settings after resetting all settings.

To call up the **SW update from USB stick** page:

-or-

The **SW update from USB stick** page appears.



Software updates are provided by the service technician as well as via the Internet.

To install the software update from USB stick:

- ► Insert USB stick with the update into the central controller.
- ► Select SW update from USB stick.

The **Software update** dialogue box appears. The folder structure of the USB stick appears in the area **Select file**.

- ► Select the update file.
- ► Select Confirm.

The software update Starts. Wait screen appears for the duration of the update. The message **SW update successful** appears.

► Select **OK**.

The **Login** dialogue box appears.

To cancel the operation:

▶ Select Cancel.






→ 7.5 "Log user in and out"

19 Help

Further explanations about the product and help can be obtained on the User manual. To access the User manual, select the following options:



	Description	Description	
=	Main Menu	Access the following via the Help menu item: ACC information Open source information Terms and conditions Help	
?	Help	Guides to the User manual.	

Table 3 Main menu and help



→ 7.2 "Header"

The ACC MT central controller requires an Internet connection in order to forward fault messages and for NTP (in case no local NTP server is available). Otherwise an Internet connection is not required for operation of the ACC MT central controller.

ACC information

You can call up information on the software versions of the hardware and software components used on the central controller via the **ACC information** page.

20 Troubleshooting

20.1 Warnings and Errors



- → 16.2.4 "Scan VRF system (System scan)"
- → 18.6.2 "Restarting"
- → 18.6 "Device and updates"
- → 18.4 "Language, date and time"
- → 16.2 "System structure"



Fault code	Error description	Test procedure/Cause	Action	
yX1	Communication fault	Fault in the communication between central controller and outdoor unit connected to XYE Port y Note: y can be a value between 1 4, that specifies the port number.	 Check the XYE wiring between the central controller and outdoor unit. Repeat the system scan (Note: all userspecific settings are deleted in the process). 	
X2	Serious fault	Fault in the hardware / software of the central controller	 Restart central controller. Contact service and replace the central controller if necessary. 	
X21	Expansion card fault AC EXP	Fault of the connection to the expansion card AC EXP	 Restart central controller. Disconnect the central controller from the power supply, unplug and reinsert the expansion card. Replace the expansion card. 	
X22	PoE, insufficient performance	Power over Ethernet does not supply enough current.	Check PoE provision or equipment.Contact the system administrator.	
X23	USB interface fault	USB interface does not function correctly, e. g. over current	 Use another USB device. Restart central controller. Contact service and replace the central controller if necessary. 	
Х3	E-mail manager fault	Fault in the network or with the internet connection, or a new configuration is required in the e-mail client.	 ▶ Check setting of the e-mail client. ▶ Check internet connection. ▶ Check network cable (LAN1). ▶ Restart central controller. ▶ Contact Service. 	
X4	Software update via USB failed	Software update via USB failed for unknown reason	Repeat the USB software update.Remove the USB media and reinsert.	
X41	Software update via USB failed, rollback	Software update via USB interface failed	► Use another USB device.	
X42	Software update via USB failed, corrupt file	Software update via USB has failed due to file corruption.	Restart central controller.Contact Service.	
X43	Software update via USB failed, USB communication	Software update via USB has failed due to communication problems with the USB device.		
Х6	Date and time fault	Central controller without power supply for a longer period	Check the date and time setting, and correct.	
X61	Internet time synchronisation fault	NTP server not available. NTP server blocked by a firewall.	 Internet connection, check network cable (LAN1). Check the network configuration. Contact the system administrator. Deactivate the internet time synchronisation and set the time manually. 	
X8	Fault energy meter or fault indoor unit/outdoor unit.	There is a fault of the central controller in relation to the energy meter, indoor/outdoor unit.	► Ensure that there are no other central controller faults related to energy meters, indoor/outdoor units.	
Х9	Energy distribution memory is full.	Flash memory full.	► Generate energy report and then clear memory.	

20.2 Energy Distribution

- ▶ Make sure the SD card is plugged in and the Extension Kit is available.
 - Use a high-quality microSD card of at least 4 GB capacity (e.g., Kingston Industrial 8GB, SanDisk Extreme Pro, etc.).
 - Insert the microSD card behind the AC-EXP and reboot the ACC MT
- Make sure that the ACC MT is connected to the Internet (or Intranet with local NTP server), and the NTP is enabled and successfully synchronized.
- ► Make sure that all IDUs and ODUs are visible in the System monitor. In case of AF6300, the S-Box parameters also needs to be visible.

- ► Make sure that the energy meters were successfully connected. In case of a connection failure:
 - Check the correct Baud rate for Modbus/RTU.
 - Check the correct address on the Energy meter.
 - Check the cabling.
- Make sure that the ACC MT receives values from the Energy meter (e.g., Voltage L1, L2 & L3 should be ~230 V) in the Energy meter overview.

The Active power shows the current energy consumption of the ODU and should be higher than 0.



- Check the Energy meter mapping. Make sure that all ODUs are assigned to an Energy meter. It is not possible to share an Energy meter between 2 VRF-Systems. In case of a cascade:
 - Either all ODUs can be assigned to 1 Energy meter.
 - Or each ODU can have its own Energy meter.
- Make sure that there are no open errors with the VRF-system and the Energy meter.

A permanently occurring of the following errors can indicate a cabling issue:

- X7: Energy meter malfunction¹⁾.
- X1: Communication fault XYE¹⁾.
- In case of a restart, wait at least 3 minutes before activating the Energy distribution.

21 Environmental protection and disposal

Environmental protection is a fundamental corporate strategy of the Bosch Group.

The quality of our products, their economy and environmental safety are all of equal importance to us and all environmental protection legislation and regulations are strictly observed.

We use the best possible technology and materials for protecting the environment taking account of economic considerations.

Packaging

Where packaging is concerned, we participate in country-specific recycling processes that ensure optimum recycling.

All of our packaging materials are environmentally compatible and can be recycled.

Used appliances

Used appliances contain valuable materials that can be recycled. The various assemblies can be easily dismantled. Synthetic materials are marked accordingly. Assemblies can therefore be sorted by composition and passed on for recycling or disposal.

Old electrical and electronic appliances

This symbol means that the product must not be disposed of with other waste, and instead must be taken to the waste collection points for treatment, collection, recycling and disposal.

The symbol is valid in countries where waste electrical and electronic equipment regulations apply, e.g. "(UK) Waste Electrical and Electronic Equipment Regulations 2013 (as amended)". These regulations define the framework for the return and recycling of old electronic appliances that apply in each country.

As electronic devices may contain hazardous substances, it needs to be recycled responsibly in order to minimize any potential harm to the environment and human health. Furthermore, recycling of electronic scrap helps preserve natural resources.

For additional information on the environmentally compatible disposal of old electrical and electronic appliances, please contact the relevant local authorities, your household waste disposal service or the retailer where you purchased the product.

You can find more information here:

www.bosch-homecomfortgroup.com/en/company/legal-topics/weee/

62

¹⁾ For more information on the error, see the 20.1 "Warnings and Errors" section.

