



(this drawing represents an ELHB 40 - for other capacities, the length to diameter ratio may differ)

51.004	Terminal box	D10.002	Supply flow adapter piece Option
D05.001	Inspection opening water-side	D11.000	Return flow
D06.002	Lifting eye	D12.001	Drain shut-off valve
D08.000	Pressure safeguard valve 1	D12.003	Dirt trap boiler
D08.100	Pressure safeguard valve 2 Option	D24.001	Heating bundle
D10.000	Supply flow	D24.002	Terminal box for the heating bundle

Explanation of symbols

A

Warning: dangerous electrical voltage



Connection option for equipotential bonding



Lifting equipment to be fastened



Warning: hot surface, e.g. uninsulated fitting



BOSCH

Version 1 (11/24)

Electric Hot Water Boiler ELHB



DA448 Version 1 (11/24)

Boiler type					Dimension(s)		
	L 1	L 2 ¹⁾	B 1 ¹⁾	B 2	В 3	B 5	H 1	H 2 ¹⁾
	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
ELHB 10	3338	2786	500	365	450	500	1849	1020
ELHB 20	2872	2320	760	365	450	760	2015	1186
ELHB 30	3901	2999	1000	375	465	1000	2267	1438
ELHB 40	4193	3291	1000	390	475	1000	2308	1479
ELHB 50	4478	3576	1000	430	515	1000	2399	1530
ELHB 60	4553	3612	1400	430	515	1400	2754	1798

Boiler	Heating bundle	Base frame		Outer diameter	Weight			
type	L 10 ²⁾	L 4	B 4	H10	D	Transportation weight	Heating bundle	Total weight
						(incl. equipment)		(full)
	[mm]	[mm]	[mm]	[mm]	[mm]	[kg]	[kg]	[kg]
ELHB 10	3079	2550	160	510	369	660	115	700
ELHB 20	2580	2200	160	527	420	850	230	900
ELHB 30	3435	2350	160	603	524	1450	590	1600
ELHB 40	3697	2750	160	603	607	2160	1000	2400
ELHB 50	3972	2750	160	564	708	3080	1560	3500
ELHB 60	4033	2750	160	565	810	4400	2440	5000

• References and defaults to requirements for the boiler installation room, see in technical information TI024.

- If dimensions are missing, the parts are not included in the scope of delivery.
- The scope of delivery is fixed in the order confirmation.
- Where dimensions or weights are specified on the datasheet, the following tolerances apply: measurements ± 1%; transportation weight ± 4%; maximum weight ±2% (also refer to Technical information TI024, chapter Pipe system).
- The shipping weight specification already includes surcharges for usual plate thickness tolerances, therefore deviations downwards are possible.
- Shown with insulation: 100 mm
- Dimensioning of the insertion opening:
 - Insertion height: surcharge of at least 100 mm on dimension H1 or dimension H2 (mounted / unmounted fittings)
 - Insertion width: add at least 200 mm to dimension B1 or dimension B2 (mounted / unmounted fittings)
- ¹⁾ Smallest transport dimensions when fittings, heating bundle and terminal box are dismantled.
- ²⁾ The length of the heating bundle must be taken into account when setting up the boiler. There must be enough space to be able to pull off the heating bundle. (Guideline: Length of heating bundle + maneuvering safety).